


KOMATSU® SEAL KITS

Part No.	Application	Machine Model
707-98-45700 (A)	ARM	PC100U-3
707-98-46200	BOOM	PC210-3, PC210LC-3, PW210-1
707-98-47500	BOOM	PC200-1
707-99-47660	BOOM	PC200LC-6LE, PC220-6, PC220LC-6, PC230-6
707-99-50620	BOOM	PC220LC-7, PC240LC-7K, PC240NLC-7K
707-99-58030	BOOM	PC300LC-7
707-99-58260	BOOM	PC220LC-6, PC220LC-6LC, PC220LC-6LE
707-99-58350 (B)	ARM	PC220-6, PC220LC-6, PC230-6, PC250LC-6
707-99-72300	ARM	PC300HD-7E0, PC300LC-7, PC300LL-7E0



FUEL PRIMING PUMPS

Part No.	Machine Model
517507	311, 312, 320/B, 322B L
2552969 (C)	311C, 312C, 314C, 318C, 319C, 320C, 321C, 323D



SENSORS

Part No.	Description	Model
2661475 (D)	TRANSMISSION CONTROL	572R, D10T, D11T, PL87
2661478 (E)	ROTARY	814F, 815F, 120K, 140K, 160K



LED LAMPS

Part No.	Description	Model
3861722 (F)	9 TO 32 VOLT	FLOOD LAMP
4170977	9 TO 34 VOLT	FLOOD LAMP
3838634	24 VOLT	FLOOD LAMP
4410315 (G)	24 VOLT	HEAD LAMP
3861718	24-VOLT	HEAD LAMP
3861723	9 TO 32 VOLT	FLOOD LAMP





Other Parts Now Available

Part No.	Description
2W8271	ARM A
2624084	BOOT
8R1928	BRAKE G - SERVICE
1280856	CLAMP - HOSE
2432058	CYLINDER
1728175	DISC BRAKE
4395037	FILTER AS
2444484	FILTER LUBE OIL ULTRA HIGH EFF.
2988533	MIRROR
1086503	PISTON
1929219	PLATE
0996530	PLATE FRICTION
1673866	PLATE FRICTION
1673862	PLATE RETAINER
0996531	PLATE SEPARATOR
1673865	PLATE SEPARATOR
990333	PLATE VALVE
3603682	PLUG
1100096	RING
6V7723	RING RETAINER
2316805	RING SEAL
1838453	RING SEAL
07005-02216	SEAL

Part No.	Description
07005-00812	SEAL
2870189	SEAL
4958212	SEAL AS
5062322	SEAL AS
707-99-58320	SEAL KIT
707-98-58230	SEAL KIT
2502503	SEAL KIT
707-98-47720	SEAL KIT
707-98-58240	SEAL KIT
4640509	SEAL O RING
5I8423	SEAL O RING
4214024	SEAL U CUP.
4214025	SEAL U CUP.
4392695	SEAL U CUP.
07005-01412	SEAL WASHER
3128934	SERPENTINE BELT - 8PK
2269381	SERPENTINE BELT - 8PK
1683381	SPRING GUIDE
561-22-62910	STUD
561-22-62822	STUD
2906567	TUBE
7N7056	V - BELT SINGLE