




BEARINGS FOR KOMATSU®

| Part No. | Description | Application |
|-----------------------|------------------|---|
| 423-22-32870 | BEARING | D155A, D155AX, WA380, WA380Z, WA430 |
| 6162-23-8050 A | THRUST BEARING | S6D170, S6D170E, SA6D170, SA6D170E, SAA6D170E |
| 6136-21-8000 B | MAIN BEARING STD | 6D105, S6D105, SA6D110 |



BUSHINGS FOR KOMATSU®

| Part No. | Description | Application |
|-----------------------|---------------------------|--|
| 207-32-51140 | BUSHING, REGULAR KOMATSU® | 430FX, 430FXL, BR550JG, BR580JG, PC220LL, PC250, PC250HD, PC270, PC290, PC300, PC308, PC350, PC360 |
| 21N-70-12170 C | BUSHING KOMATSU® | BR580JG, PC1250, PC1250SP |



VALVE SEAL FOR KOMATSU®

| Part No. | Description | Application |
|-----------------------|---------------------------|-------------|
| 6754-41-4540 D | SEAL, VALVE STEM KOMATSU® | 35, 45, 55 |



* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.