



CTP Air Conditioning Compressors

CTP Air Conditioning Compressors -

The Air Conditioning Compressor's main function is to compress and pump the refrigerant to the condenser where it will absorb the heat from the system. Compressors are considered to be the heart of the A/C system.

Use CTP quality Air Conditioning Compressors to keep your system running at all times.

Part No.	Engine Model
1540490	3046
3E1908	3054
1717495	3066
2457781	3066
1065122	3116
2180324	3412
7N4297	3412
8T8816	3412
1149484	3116, 3126
1630872	3176C
3050325	C7
1789570	C9
3050324	C9
2777245	C11
1835106	C15

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.