



CTP Cables

CTP cables are simple to install and easy to maintain in order to provide you with low costs throughout the products' life cycle.

Braking System Cables

Part No.	Application	Machine Model
1061858	Service Break	950F, 960F
1088100	Break Group	814F, 815F, 816F, 950F, 960F, 966F, 970F
1445323	Clutch & Break Control	12H, 120H, 135H, 140H, 143H, 160H, 163H
1479654	Parking Break	950G, 962G, 962G II, IT62G
1630755	Parking Break	416C/D, 420D, 424D, 428C/D, 430D, 432D, 436C, 438C/D, 442D, 446D
3E1804	Service Break	834B, 836, 988B, 988F
4D3270	Service Break	120B, 140B, 12
4D7345	Clutch & Brake Control	12, 120B, 140B
4V2157	Parking Break	814B, 815B, 816B, 824C, 825C, 826C, 950B, 966D, 980C
6C1581	Service Break	966F, 970F
6D1562	Clutch & Brake control	120, 140
7X1799	Steering & Braking system	D8N, D8R, D7H & D7H LGP
7X1906	Steering & Braking system	D6H, D6H LGP
8D5287	Clutch & Brake control	12G, 130G, 140G, 160G
8D5288	Clutch & Brake control	14G
9D4635	Clutch & Brake control	120G
9U0691	Parking Break	IT18F, IT24F, IT28F, 918F, 924F, 928F, 938F
9X5694	Clutch & Brake Control	12H, 16H, 120H, 135H, 140H, 160H, 163H

Electrical & Starting System Cables

Part No.	Application	Machine Model
1706929	Electrical & Starting System	313D2 LGP, 314D LCR, 315C & 315C L, 318D2 L, 320C, 320C L, 320D L, 323D2 L, 324D, 324DL, 325D L, 329D L, 330C L, 336D2 L, 345D, 621K, 623K, 627K
3L8048	Electrical & Starting System	N/A
7P6682	Electrical & Starting System	D4H LGP, D5N, D6R, D6T, 416B, 428B, 815B, 943, 953, 960F, 973C, PM-565

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions.
Part Numbers are used for reference purposes only

Cables for Lock System

Part No.	Application	Machine Model
1166531	Lock-Transport	416B, 426B, 436B
1178774	Lock-Transport	416C
1137398	Lock-Transport	428B, 438B
1742365	Lock-Transport	416C, 426C, 436C

Fuel System Cables

Part No.	Application	Engine Model
1042128	Governor	3054
1742297	Governor	3054B, 3116
2037100	Governor	3116, 3054
2350128	Governor	3054C, 3054B, C4.4
5G2315	Governor	3204
6T8466	Governor	3204, 3304
6T8467	Governor	3304
6T8468	Governor	3306, 3406C
6T8469	Governor	3406
8C9586	Governor	3306, 3306B
9D0148	Governor	3306, 3306D
9D1611	Governor	3304, 3306, 120G
9X0391	Governor	3306, 816F
9X4776	Governor	3114
9X4857	Governor	3408
9X5476	Governor	3408
1311990	Governor	3126
1641079	Governor	3054, 3054B, 3114
1766767	Governor	3126, 3306, 3406C
9X1336	Governor	3306
9X4219	Governor	3306, 3406/B

Frame and Body Cable

Part No.	Application	Machine Model
1641183	Frame Grp- Swing	416D, 420D
2220844	Frame Grp- Swing	416D, 420D, 430D

Undercarriage Track Adjuster Cables

Part No.	Application	Machine Model
7G8282	Undercarriage Track	D7H, D8L/T, D9T/L/R, D10N, D10R, D10T2, D11R/T, PL83, PL87, 583R

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions.
Part Numbers are used for reference purposes only

Power Train Cables

Part No.	Application	Machine Model
2V7617	Transmission Ctrl.	834B, 988B
7V9142	Transmission Ctrl.	930/R/T
7V9223	Transmission Ctrl.	966C/R
8C5604	Transmission Ctrl.	D3C, D4C, D5C, 931C, 933
8D5286	Transmission Ctrl.	12G, 130G, 140G, 160G
8D5289	Transmission Ctrl.	14G
8V8022	Transmission Ctrl.	966C/R
9D4634	Transmission Ctrl.	120G
9D4635	Transmission Ctrl.	120G
9G8630	Transmission Ctrl.	D8L, D9L/N/R, D10N
9G8631	Transmission Ctrl.	D8L, D9L/R, D10N,
1V6350	Transmission Ctrl.	834B, 836, 988B

Operator Cables -

Part No.	Application	Machine Model
3V2783	Station install	814B, 815B, 816B, 824C, 825C, 826C, 966D, 980C
3V7125	Station install	824C, 825C, 826C, 980C/F
4V4835	Station install	950B
5V4732	Station install	814B, 815B, 950B/E, 966D/E/F
5V4734	Station install	814B, 815B, 816B, 950B, 966D/E
6T1313	Station install	G936, 936/E/F
6T1314	Station install	G936, 936/E/F
7T1971	Station install	815B, 824C, 825C, 826C
8V0554	Station install	824C, 825C, 826C, 980C/F
9X0391	Station install	814F, 815F, 816F, 970F
9D2141	Indicator GP	12G, 120G, 130G, 140G, 160G
9X0390	Station install	IT18B, IT28B, 916, 926E, 936E/F, 966E
9X1147	Station install	IT18B, IT28B, G916, D3C, D4C, D5C, 926E
9X1395	Station install	950E
9X5426	Station install	950F, 960F
9X5695	Station install	950F, 966F
1406705	Station install	938G, IT38G
3V7096	Station install	824C, 825C, 826C, 980C/F

Work Tools Cables

Part No.	Application	Machine Model
3V9180	Winch Control	528