



CTP Switches

CTP Switches -

Part No.	Description
0302266	SWITCH
0993955	SWITCH A
1056117	SWITCH A
1056118	SWITCH A
1070611	SWITCH A
1070616	SWITCH AS
1107887	SWITCH A
1107887C	SWITCH
1145333	SWITCH A
1199631	SWITCH
1199985	SWITCH A
1262938	SWITCH
1285091	SWITCH AS
1327450	SWITCH AS
1352362	SWITCH AS
1421305	SWITCH AS
1428858	SWITCH A
1543986	SWITCH
1586634	SWITCH AS
1632659	SWITCH AS
1655970	SWITCH

Part No.	Description
1718710	SWITCH GP
1718711	SWITCH GP
1753244	SWITCH AS
2L3402	SWITCH
2M9346	SWITCH
2N7124	SWITCH
2N9768	SWITCH
2Y2397	SWITCH A
2Y2398	SWITCH AS
2029002	SWITCH AS
2033221	SWITCH AS
2033222	SWITCH AS
2033223	SWITCH AS
2081093	SWITCH-PRE
2095582	SWITCH AS
2351790	SWITCH
2381596	SWITCH AS
2537910	SWITCH AS
2666210	SWITCH
3D9718	SWITCH
3E0156	SWITCH A

Part No.	Description
3E2026	SWITCH
3E2030	SWITCH G
3E5464	SWITCH A
3E5465	SWITCH A
3E9350	SWITCH A
3E9350C	SWITCH A
3K1650	SWITCH
3P8990	SWITCH A
3T2357	SWITCH
3T3132	SWITCH A
3T3421	SWITCH A
3T5825	SWITCH
3T6655	SWITCH A
3Y4424	SWITCH A
3095768	SWITCH AS
3095769	SWITCH AS
3135104	SWITCH AS
3495382	SWITCH
4D4785	SWITCH
6P3236	SWITCH A
6T1546	SWITCH A

Part No.	Description
6T4949	SWITCH A
6T6652	SWITCH A
6T7663	SWITCH A
7N0718	SWITCH A.
7N4160	SWITCH G
7N5933	SWITCH
7N5946	SWITCH
7N8005	SWITCH
7S6402	SWITCH
7T0988	SWITCH A
7V5647	SWITCH A.
7Y3918	SWITCH G
8D2676	SWITCH
8V7195	SWITCH A
8Y7237	SWITCH A
9G7641	SWITCH G
9G8010	SWITCH A
9G8011	SWITCH A
9N1750	SWITCH
9W1077	SWITCH A
9X4959	SWITCH A

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only