



BACKHOE LOADER PADS

Part No.	Description	Machine
1378894	PAD AS	426C, 436C
1378898	PAD AS	428C, 438C
1873825	PAD AS	416D, 420D, 432D, 428D, 424D
1873826	PAD AS	416D, 420D, 432D, 428D, 424D
1873827	PAD AS	416D, 430D, 428C, 438C, 432D
1873828	PAD AS	416D, 430D, 428C, 438C, 432D
1873829	PAD AS	416D, 430D, 428C, 438C, 432D
1921699	PAD AS	426C, 436C
1931681	PAD	428C, 438C
1931682	PAD	428C, 438C
1931683	PAD	428C, 438C
1931684	PAD	428C, 438C
1931685	PAD	428C, 438C

Part No.	Description	Machine
1931686	PAD	428C, 438C
1931687	PAD	428C, 438C
1931688	PAD	428C, 438C
1931689	PAD	428C, 438C
2171577	PAD AS	420E, 428E, 430E, 422E, 432E, 442E, 444E
2188411	PAD AS	420E, 428E, 430E, 422E, 432E, 442E, 444E
2269764	PAD AS	420E, 428E, 430E, 422E, 432E, 442E, 444E
2335169	PAD	420E, 428E, 430E, 422E, 432E, 442E, 444E
9R8231	PAD AS	438C, 436B
9R8235	PAD AS	426C, 436C, 428C, 438C
9R9579	PAD	426C, 436C, 428C, 438C

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions.
Part Numbers are used for reference purposes only.