



CTP Pad Assemblies

CTP Pad Assemblies -

CTP isolation pads decrease vibration and noise transmission, therefore significantly reducing the harmful effects of vibration that may cause serious impairment to workers and the overall effectiveness of the equipment.

- Pads are resistant to oil and solvents
- Control vibration, shock and noise
- Isolate vertical and horizontal forces
- Extend life of equipment

Part No.	Description	Machine
1068223	PAD ASSEMBLY	AD40, AD45, 769/B, 769C, 771C/D, 773B/D, 775/B
1068224	SHIM	AD40, AD45, 769/B, 769C/D, 770, 771C/D, 772, 773B/D/E/F, 775B/D/E/F
1642465	PAD	12G/H/H NA/H ES, 14G/H/H NA, 16H/H NA, 120G/H/H NA/H ES, 130G, 135H/H NA, 140G/H/H NA/H ES, 143H, 160H/H NA/H ES, 163H/H NA
1642465	PAD	-
1667870	PAD ASSEMBLY	422E, 424D, 428/B/C/D/E, 432D/E, 434E, 438/B, 438C/D, 442D/E, 444E
2137322	PAD ASSEMBLY	D9L, D10R, D10T
2137322	PAD ASSEMBLY	D9L, D10R
3P2482	PAD ASSEMBLY	D11N, D11R
3P4369	PAD	D7G
6P4327	PAD	D7F, D7G, D7H
6T0952	PAD ASSEMBLY	D8H, D8K
6T0956	PAD ASSEMBLY	D6C, D6D, D6D SR, D6F DR
6T0960	PAD ASSEMBLY	D7F, D7G
6T8907	PAD ASSEMBLY	D6C, D6D, D6D SR, D6F DR
6Y7795	PAD ASSEMBLY	D7H

Part No.	Description	Machine
6Y7796	PAD ASSEMBLY	D7H
6Y9508	PAD ASSEMBLY	D8N, D8R, D8R II, D8T
6Y9509	PAD ASSEMBLY	D8N, D8R, D8R II, D8T
7G2704	PAD ASSEMBLY	D9L, D10R, D10T
7T4700	PAD ASSEMBLY	D8N, D8R, D8R II, D8T, VFS50, VFS70
7T5419	PAD ASSEMBLY	D9N, D9R, D9T, 574
7T5510	PAD ASSEMBLY	D8L, 578
7T5959	PAD ASSEMBLY	D9L, D10N, D10R, D11N, D11R, 589
8G8378	PAD ASSEMBLY	943, 953
8P2697	PAD ASSEMBLY	D9E, D9G
8Y8679	PAD ASSEMBLY	D6R, 416B/C, 426B/C, 436B/C, 446B, 3412E
9G1696	PAD ASSEMBLY	D8L, D9N, D9R
9G1697	PAD ASSEMBLY	D8L, D9N, D9R
9P4200	PAD ASSEMBLY	D8H, D8K

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.