



# CARRIERS

Our carriers are manufactured from quality cast iron and tempered to remove any stresses due to processing. CTP Carriers are packaged in paper or nylon bags that are chemically treated to prevent corrosion during extended storage under unfavorable conditions.

Part No.	Description	Application
1043133	CARRIER-PLANETARY	589, D9N, D9R, D9T
1060713	CARRIER	D5R LGP, D6M, D6N, D6N LGP
1067099	CARRIER-PLANETARY	589, D10N, D10R, D10T, D10T2, D8L, D9N, D9R
1085621	CARRIER-PLANETARY	517, 527, D5R LGP, D6M, D6N, D6N LGP
1107058	CARRIER-PLANETARY	320B, 322B L, 325 L, 325B, 325B L
1107059	CARRIER-PLANETARY	320B, 322B L, 325 L, 325B, 325B L
1107209	CARRIER	320B, 322B L, 325 L, 325B, 325B L
1107228	CARRIER-PLANETARY	330B, 330B L
1107243	CARRIER AS	330B, 330B L
1127307	CARRIER	528B, 530B, 735, 814B, 815B, 816B, 966D, 966F, D25C, D25D, D30C, D350C, D350E, D350E II, D35C, D35HP, D400
1127308	CARRIER-PLANETARY	589, 834B, 834G, 834H, 834K, 836, 836G, 836H, 836K, 986H, 988G, 988H, 988K, AD30, D350E, D350E II, D400E, D9N, D9R, D9T, R2900, R2900G, R3000H
1128041	CARRIER-PLANETARY	814B, 814F, 815B, 815F, 816F, 966D, 966F, 966F II, 966G, 966G II, 970F, 972G, 972G II, 972H, 972M, 980C, 980F, 980F II, D6H, D6H XL, D6H XR, D6R, D6R II, D6R III, D6R STD, D6T, D6T LGP, D6T LGPPAT
1128042	CARRIER-PLANETARY	572R, 572R II, 578, 583R, 814F, 814F II, 815F, 815F II, 816F, 816F II, 972H, 972K, 980F, 980F II, 980G, 980G II, 980H, 980K, 980M, D7H, D7R, D7R II, D7R XR, D8N, R1600, R1600G, R1600H, R1700 II, R1700
1293046	CARRIER-PLANETARY	824G, 824G II, 824H, 824K, 980G, 980G II, 980H, 980K, 980K HLG, 980M, AD30, R1700G
1294300	CARRIER-PLANETARY	966G, 966G II, 966H, 966K, 972G, 972G II, 972H, 972K, IT38G II

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## Carriers - Cont.

Part No.	Description	Application
1484637	CARRIER-PLANETARY	318C, 318E L, 319C, 319D, 319D L, 319D LN, 320C, 320C FM, 320C L, 320D, 320D FM, 320D FM RR, 320D GC, 320D L, 320D LN, 320D LRR, 320D RR, 320D2, 320D2 GC, 320D2 L, 320E, 320E L, 320E LN, 320E LRR
1620270	CARRIER-PLANETARY	988B, 988F
1864117	CARRIER AS	416B, 416C, 416D, 420D, 424D, 426C, 428B, 428C, 428D, 430D, 432D, 436C, 438C, 438D, 442D, CS-531C, CS-531D, CS-533C, CS-533D, CS-563C, CS-563D, CS-573C, CS-573D, CS-583C, CS-583D
1912571	CARRIER-PLANETARY	320C, 320C FM, 320D, 320D FM, 320D FM RR, 322C, 322C FM, 323D LN, 323D SA, 323E L, 324D, 324D L, 324D LN, 324E, 324E L, 324E LN, 325C, 325C FM, 325D, 325D L, 325D MH, 326D L, 329D, 329D L, 329D LN,
1912578	CARRIER-PLANETARY	318C, 318E L, 319C, 319D, 319D L, 319D LN, 320C, 320C FM, 320C L, 320D, 320D FM, 320D FM RR, 320D GC, 320D L, 320D LN, 320D LRR, 320D RR, 320D2, 320D2 GC, 320D2 L, 320E, 320E L, 320E LN, 320E LRR
1912678	CARRIER AS	322C, 322C FM, 324D, 324D L, 324D LN, 324E, 324E L, 324E LN, 326D L
1912686	CARRIER AS	320C, 320C FM, 320D, 320D FM, 320D FM RR, 322C, 323D LN, 323D SA, 323E L, 325C, 325C FM, 325D, 325D L, 325D MH, 329D, 329D L, 329D LN, 329E, 329E L, 329E LN
2094159	CARRIER	902, 906, 906H, 906H2, 907H, 907H2, 908H, 908H2, TH210, TH215
2105924	PLANETARY GP-FINAL DRIVE	414E, 416D, 416E, 416F, 420D, 420E, 420F, 422E, 422F, 424D, 428D, 428E, 428F, 430D, 430E, 430F, 432D, 432E, 432F, 442D, 442E, 450E, 450F, TH220B, TH330B, TH340B, TH350B, TH355B
2105943	CARRIER-PLANETARY	416D, 416E, 416F, 420D, 420E, 420F, 422E, 422F, 424D, 428D, 428E, 428F, 430D, 430E, 430F, 432D, 432E, 432F, 442D, 442E, 450E, 450F, TH220B, TH330B, TH340B, TH350B, TH355B
2161601	CARRIER	414E, 416E, 416F, 420E, 420F, 422E, 422F, 428E, 428F, 430E, 430F, 432E, 432F, 434E, 434F, 442E, 444E, 444F, CP-533E, CP-54B, CS-533E, CS-54, CS-54B, CS-563E, TH460B
2676799	CARRIER-PLANETARY	320D, 320D FM, 320D FM RR, 322C, 323D LN, 323D SA, 323E L, 324D, 324D L, 324D LN, 324E, 324E L, 324E LN, 325C, 325D, 325D L, 325D MH, 326D L, 329D, 329D L, 329D LN, 329E, 329E L, 329E LN,
2698417	GEAR-PLANETARY	16M
3208565	CARRIER	TH414C
4248845	CARRIER-PLANETARY	16M
1M4153	CARRIER	594, 594H, D8H, D8K, D9G, D9H
1T1481	CARRIER-RING	936, 950B, 950B/950E, 950F, 966R, G936
1V1409	CARRIER	910, 920
1V2281	CARRIER	518, 613, 613B, 950
1V3335	CARRIER	518, 930
2P4408	CARRIER	518, 528, 920, 930, 941, 951B, D4D, D4E
2V5722	CARRIER	528B, 530B, 735, 814B, 815B, 816B, 966D, 966F, D25C, D25D, D30C, D350C, D350E, D350E II, D35C, D35HP, D400
3P0298	CARRIER-INPUT	120G, 12G, 130G, 140G, 160G
3P0306	CARRIER-PLANETARY	120G, 12G, 130G, 140G, 160G
3P0862	CARRIER-INPUT	14G, 14H, 14H NA, 16G, 16H, 16H NA
3P1609	CARRIER-PLANETARY	14G, 14H, 14H NA, 16G, 16H, 16H NA
3P2415	CARRIER-PLANETARY	824C, 824G, 824G II, 824H, 824K, 825G, 825G II, 825H, 825K, 826C, 826G, 826G II, 826H, 826K, 834B, 836, 980C, 980F, 980F II, 980G, 980G II, 980H, 980K, 980K HLG, 980M, 982M, 988B, 988F, 988F II
3P3775	CARRIER-PLANETARY	589, 834B, D400, D44B, D550B, D9L, D9N
3T3294	CARRIER-PLANETARY	D10N, D10R, D10T, D10T2, D9L

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## Carriers - Cont.

Part No.	Description	Application
4E2166	CARRIER-PLANETARY	515, 518C, 525, 936F, 938F, 938G, 938G II, IT38F, IT38G, IT38G II
4S5940	CARRIER ASSEM.	814, 950, 955K, 955L, 966C, D5B
4S5980	CARRIER	
4V5237	CARRIER-PLANETARY	611, 615, 615C, 735, 735B, 740, 740B, 816B, 966G, D25D, D400E, D400E II, D40D, R1600, R1600G, R1600H
4V8541	CARRIER-PLANETARY	518, 528, 613C, 613C II, 613G, 730, 730C, 950B, 950B/950E, D300E, D300E II, R1300, R1300G, R1300G II
4V9823	CARRIER-PLANETARY	916, CS-643, IT18B
5M7875	CARRIER-FRONT	14E, 572G, 977K, 977L, D6C, D6D, D6E, D6G, D6G2 LGP, D6G2 XL, D7F, D7G, D7G2
5S0887	CARRIER	920, 930, 941, 951B, D4D
5S0889	CARRIER ASSEM.	518, 528, 920, 930, 941, 951B, D4D, D4E
5S4493	CARRIER	814, 950, 955K, 955L, 966C, D5, D5B
5S7023	CARRIER	814, 950, 955K, 955L, 966C, D5, D5B
5V6177	CARRIER-PLANETARY	508, 518, 936, D250B, D300B, D300D, G936
6C0739	CARRIER AS	215, 215B, 215C
6G7213	CARRIER-PLANETARY	120G, 120H, 120H ES, 120H NA, 120K, 120K 2, 135H, 135H NA
6G7214	CARRIER	
6I8309	CARRIER	631E, 631G, 633E II, 637E, 637G, 657E, 657G
6P0748	CARRIER-PLANETARY	910, 916, 926, 926A, 931B, 931C, 931C II, 933, D3C, D3C III, D4B, D4C, D4C III, IT18B, IT28
6S3011	CARRIER	910
6T0275	CARRIER	926, IT28, IT28B
6T3726	CARRIER AS	89, 834B, AD30, D350E, D350E II, D400, D400E, D44B, D550B, D9L, D9N, D9R, D9T, R2900, R2900G, R3000H
6Y1336	CARRIER-PLANETARY	583T, 587R, 587T, D8N, D8R, D8R II, D8T, PL83, PL87, PM-201, PM-465, PM-565B
6Y1604	CARRIER AS	980C, 980F, 980F II
6Y2109	CARRIER-SEAL	936, 936F, 950B, 950B/950E, 950F, 950F II, 950G, 950G II, 950H, 950K, 960F, 962G, 962G II, 962H, 962K, 966C, 966H, 966K, 966M, G936, IT62G, IT62G II, IT62H, R1300, R1300G, R1300G II
6Y4819	CARRIER-PLANETARY	578, 814B, 814F, 815B, 815F, 816F, 966D, 966F, 966F II, 966G, 966G II, 970F, 972G, 972G II, 972H, 972K, 972M, D6H, D6H XL, D6H XR, D6R, D6R II, D6R III, D6R STD, D6T, D6T LGP, D6T LGPPAT, D6T XL, D7H
6Y4846	CARRIER-PLANETARY	572R, 572R II, 583R, 583T, 587R, 587T, D7H, D7R, D7R II, D7R XR, D8N, D8R, D8R II, D8T, PL83, PL87
6Y7879	CARRIER-PLANETARY	950F II, 950G, 950G II, 950H, 950K, 960F, 962G, 962G II, 962H, 962K, 966C, IT62G, IT62G II, IT62H, R1300G II
7G4589	CARRIER-PLANETARY	980C, 980F, 980F II
7G5444	CARRIER-PLANETARY	561M, 561N, 936, 936F, 950B, 950B/950E, 950F, 950F II, 950G, 950G II, 950H, 950K, 960F, 962G, 962G II, 962H, 962K, 966C, 966H, 966K, 966M, 966R, D4H XL, D4HTSK III, D5H, D5H XL, D5HTSK II, D5M, D5N
7G5445	CARRIER-PLANETARY	613C, 613C II, 613G, 936, G936
7G5684	CARRIER-PLANETARY	572R, 572R II, 578, 583R, D6R, D7H, D7R, D7R II, D7R XR
7G7218	CARRIER-PLANETARY	572R, 572R II, 578, 583R, 814B, 814F, 814F II, 815B, 815F, 815F II, 816F, 816F II, 966D, 966F, 966F II, 966G, 966G II, 970F, 972G, 972G II, 972H, 972K, 972M, 980C, 980F, 980F II, 980G, 980G II, 980H

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## Carriers - Cont.

Part No.	Description	Application
7G8211	CARRIER AS	589, 824C, 824G, 824G II, 824H, 824K, 825G, 825G II, 825H, 825K, 826C, 826G, 826G II, 826H, 826K, 980G, 980H, 980K, 980K HLG, 980M, 982M, D8L, D9N
7I7728	CARRIER-PLANETARY	1090, 1190, 1190T, 1290T, 1390, 2290, 2390, 2391, 2491, 2590, 322 FM L, 322B L, 322B LN, 322C, 322C FM, 324D, 324D FM, 324D FM LL, 324D L, 324D LN, 324E, 324E L, 324E LN, 325B, 325B L, 325C, 325C FM
7K1848	CARRIER	815, 966C
7T1124	CARRIER AS	589, D8L
7T2531	CARRIER-PLANETARY	572R, 572R II, 578, 583R, D6R, D7H, D7R, D7R II, D7R XR
7T3365	CARRIER-PLANETARY	D8N, R1600, R1600G, R1600H, R1700 II, R1700G
7T8170	CARRIER-PLANETARY	926, 939, D4H, D4HTSK II, D5C, D5C III, IT28
7Y0228	CARRIER AS	325, 325 LN
7Y0241	CARRIER	325, 325 LN
7Y0242	CARRIER	325, 325 LN
7Y0643	CARRIER	325 L, 328D LCR, 330, 330 FM L, 330 L, 330C L, 330D, 330D L, 330D LN, 330D MH, 336D, 336D L, 336D LN
7Y0645	CARRIER	325 L, 325C, 328D LCR, 330, 330 FM L, 330 L, 330B, 330B L, 330C, 330C FM, 330C L, 330C MH, 330D, 330D L, 330D LN, 330D MH, 336D, 336D L, 336D LN
7Y0731	CARRIER	325 L, 325C, 328D LCR, 330, 330 FM L, 330 L, 330C, 330C FM, 330C L, 330C MH, 330D, 330D L, 330D LN, 330D MH, 336D, 336D L, 336D LN
7Y1238	CARRIER	322 FM L, 322B L, 322B LN, 325, 325 L, 325 LN, 325B, 325B L, 330D FM, 345B II, 345B II MH, 345B L, 345C, 345C L, 345C MH, 345D, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L HVG, 349E L VG
7Y1432	CARRIER	315C, 315D L, 318B, 318C, 318E L, 319C, 319D, 319D L, 319D LN, 320 L, 320B, 320C, 320C FM, 320C L, 320D, 320D FM, 320D GC, 320D L, 320D LN, 320D LRR, 320D RR, 320D2, 320D2 GC, 320D2 L, 320E, 320E L
7Y1433	CARRIER	315C, 315D L, 318B, 318C, 318E L, 319C, 319D, 319D L, 319D LN, 320 L, 320B, 320C, 320C FM, 320C L, 320D, 320D FM, 320D GC, 320D L, 320D LN, 320D LRR, 320D RR, 320D2, 320D2 GC, 320D2 L, 320E, 320E L
7Y1751	CARRIER-PLANETARY	320 L, 320B, 320B L, 320N, 321B
7Y1752	CARRIER-PLANETARY	320 L, 320B, 320B L, 320N, 321B
7Y1771	CARRIER	320 L, 345B, 345B L
7Y1774	CARRIER	320 L, 345B, 345B L
8D2532	CARRIER-PLANETARY	14G, 14H, 14H NA
8D3591	CARRIER-PLANETARY	12G, 12H, 12H ES, 12H NA, 12K, 130G, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 143H, 160G, 160H, 160H ES, 160H NA, 160K, 163H, 163H NA
8E2974	CARRIER AS	980F, 980F II, 980G, 980G II, 980H, 980K, 980M
8E4024	CARRIER-PLANETARY	910, 916, 931B, 931C, 931C II, 933, D3C, D3C III
8E4589	CARRIER AS	910, 916, 926, 931B, 931C, 931C II, 933, D3C, D3C III, D4C, D4C III, IT18B, IT28B
8G6335	CARRIER-PLANETARY	953, 953B
8G7133	CARRIER AS	963, 963B
8M8677	CARRIER-REAR	14E, 572G, 977K, D6C, D6D, D6E, D6G, D6G2 LGP, D6G2 XL, D7F, D7G, D7G2
8P5777	CARRIER-RING	980C, 980F, 980F II, 980G, 980H, 980K, 980M
8P5778	CARRIER-RING	980C, 980F, 980F II, 980G, 980G II, 980H, 980K, 980M
8R2198	CARRIER-PLANETARY	928F, 928G, 928H, 928HZ, IT18F, IT28F, IT28G

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## Carriers - Cont.

Part No.	Description	Application
8R2537	CARRIER-PLANETARY	918F, 924F, 924G, 924GZ, 924H, 924HZ, 924K, IT18F, IT24F
8R4571	CARRIER-PLANETARY	950F, 950F II, 950G, 950G II, 950H, 950K, 960F, 962G, 962G II, 962H, 962K, IT62G, IT62G II, IT62H
8R4821	CARRIER-PLANETARY	824C, 980C, 980F, 980F II, AD40, AE40, D40D, R1700 II
8S9070	CARRIER ASSEMBLY	D7F
9C6027	CARRIER	814F, 814F II, 815F, 815F II, 816F, 816F II, 966F, 966F II, 970F, D6R
9D8794	CARRIER-PLANETARY	772, 772B, 773B, 773D, 773E, 775B, 775D, 775E
9G1490	CARRIER-PLANETARY	561M, 561N, 936, 936F, D4H XL, D4HTSK III, D5M, D5N, G936
9G1491	CARRIER-PLANETARY	950B, 950B/950E, 950F, 950F II, 950G, 950G II, 950H, 950K, 960F, 962G, 962G II, 962H, 962K, 966C, 966H, 966K, 966M, 966R, D5H, D5H XL, D5HTSK II, IT62G, IT62G II, IT62H, R1300, R1300G, R1300G II
9G9175	CARRIER	D6H, D6H II, D6H XL, D6H XR, D6R, D6R II, D6R III, D6R STD, D6T, D6T LGP, D6T LGPPAT, D6T XL
9K1759	CARRIER	528, 814, 815, 966C
9P3468	CARRIER-PLANETARY	589, D8L, D9N, D9R, D9T
9P3663	CARRIER	594H, D8K, D9H
9P3731	CARRIER-PLANETARY	966D, 966F, 966F II, 966G, 966G II, 970F, 972G
9P8451	CARRIER-PLANETARY	120G, 12G, 130G, 140G, 160G
9W0517	CARRIER-PLANETARY	517, 527, 950B, 950B/950E, 950F, 950F II, 950G, 950G II, 950H, 950K, 960F, 962G, 962G II, 962H, 962K, 966C, 966H, 966K, 966M, D5H, D5H XL, D5HTSK II, D6M, IT62G, IT62G II, IT62H, R1300, R1300G, R1300G
9W3605	CARRIER-RING	615, 615C, 814B, 814F, 815B, 815F, 816F, 966D, 966F, 966F II, 970F, D250B, D250E, D25C, D300E, D6H, D6H XL, D6H XR, D7H, D8N, R1600, R1600G, R1600H, R1700 II, R1700G
9W4949	CARRIER-PLANETARY	950B, 950B/950E, 950F, 950F II, 966R, R1300, R1300G
9W4957	CARRIER-PLANETARY	936, 936F, G936
9W6046	CARRIER AS	926, 939, D4H, D4HTSK II, D5C, D5C III, IT28B
9W7839	CARRIER-PLANETARY	D6H, D6H XL, D6H XR, D6R, D6R II, D7H, D7R II, D8N
9W9392	CARRIER-PLANETARY	583T, 587R, 587T, D8N, D8R, D8R II, D8T, PL83, PL87
9W9396	CARRIER-PLANETARY	D8N, D8R

## Carriers For Komatsu®

Part No.	Description	Application
207-26-71570	CARRIER KOMATSU®	PC220LL, PC270LL, PC300, PC300HD, PC340, PC350, PC350HD, PC360, PC380, PC390
20Y-26-21150	CARRIER KOMATSU®	PC200, PC200Z, PC210, PC220, PC228UU, PC230, PC240
20Y-27-21140	CARRIER KOMATSU®	PC100L, PC200, PC210, PC220, PC230, PC240
20Y-27-21153	CARRIER KOMATSU®	CD110R, PC100L, PC200, PC210, PC220, PC230, PC240, PC300, PC300SC, PC340, PC350, PC380
20Y-27-22170	CARRIER KOMATSU®	BP500, BR200J, BR200S, BR200T, BR250RG, BR300J, BR300S, BR310JG, BR350JG, BR380JG, COOLANT, CS360, CS360SD, PC100L, PC160, PC180, PC200, PC200CA, PC300, PC600, PC650, PC700

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.