



BRAKE PEDALS

Brake Pedal Assemblies

Part No.	Description	Application
2R0617	VALVE AS-BRAKE FOOT CONTROL	814, 815, 816, 920, 930, 930R, 950, 966C, 966R, 980, 980B
4V4154	VALVE AS-BRAKE	814B, 815B, 816B, 824C, 825C, 826C, 916, 926, 926A, 936, 936F, 950B, 950B/950E, 950F, 950F II, 960F, 966D, 966F, 966F II, 970F, 980C, G916, G926, G936, IT18, IT18B, IT28, IT28B, RM-250C, RR-250B

Pedals and Valves

Part No.	Description	Application
1196744	VALVE GP-BRAKE CONTROL	814F, 815F, 816F, 924F, 938F, 950F, 950F II, 960F, 966F, 966F II, 970F, IT24F, IT28F, IT38F, R1300, R1300G, R1300G II
2R0696	TREADLE ASSEM.	920, 930, 950
4D2287	VALVE AS	621, 621B, 621E, 623, 623B, 623E, 627, 627B, 631C, 631D, 631E, 633C, 633D, 637, 637D, 637E, 641, 641B, 650B, 651, 657, 657B, 666, 666B, 768B, 769, 814, 814B, 815, 816, 816B, 824C, 825C, 826C, 916, 920.
7D8075	VALVE AS	120G, 130G, 140G, 768B, 768C, 769, 769C, 769D, 771C, 771D, 772, 772B, 773, 773B, 773D, 775B, 775D, 776, 776C, 776D, 777, 777B, 777D, 784B, 785, 785B, 789, 789B, 793, 793B, 793C
9V2434	TREADLE AS	815B, 826C, 926, 936F, 950F, 950F II, 980C, 980F, RM-250C, RR-250B
0300810	PEDAL HEAD	RT50

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions.
Part Numbers are used for reference purposes only