



# VALVE INSERTS

CTP valve seat inserts are manufactured with the highest quality steel alloy, comprised of a high grade nickel and chromium. These valve seat inserts are designed and manufactured to withstand the extreme temperatures and pressures produced by today's high performance diesel engines.

Part No.	Description	Engine	Equipment
1P6837	VALVE SEAT INSERT (INLET)	3306, G3304, G3306	12G, 528, 930, 950, 955K, D4D
1S2894	VALVE SEAT INSERT (INLET)	1674, 1676	621, 980, D334, D336
1S2895	VALVE SEAT INSERT (EXHAUST)	1674, 1676	621, 980, D334, D336
1S5738	VALVE SEAT INSERT (EXHAUST)	D353C, D379B, G353D, G379, G398, G399	
1W2713	VALVE SEAT INSERT (EXHAUST)	3114, 3116, 3126,	120H, 120H ES, 120H NA, 135H, 135H NA, 205B, 214B, 224B, 30/30, 320 L, 320B, 322 FM L, 322B L, 322B LN, 322C, 322C FM, 325, 325 L, 325B, 325B L, 35, 446B, 446D, 45, 525B, 533, 535B
1W5283	VALVE SEAT INSERT (EXHAUST)	3406, 3406B, 3406C, 3406E, 3408, 3408B, 3408C, 3408E, 3412, 3412C, 3412D, 3412E, 3516B,	16G, 16H NA, 245, 24H, 375, 375 L, 5080, 5110B, 578, 583R, 587R, 589, 621, 621B, 621E, 621F, 623E, 623F, 627B
1W5321	VALVE SEAT INSERT (EXHAUST)	3304, 3306	120B, 140B, 1673C, 235, 930, 955L, D6D, D7F, D7G
1039252	VALVE SEAT INSERT (INLET)	3044C	236B, 236B3, 242B3, 246C, 252B, 252B3, 256C, 257B3, 259B3, 262C, 262C2, 267B, 268B, 272C, 277C, 277C2, 279C, 279C2, 287C, 287C2, 289C, 289C2, 297C, 299C, 315, 315B, 315C, 317B LN, 318B, 906
1039253	VALVE SEAT INSERT (EXHAUST)	3044C	236B, 236B3, 242B3, 246C, 252B, 252B3, 256C, 257B3, 259B3, 262C, 262C2, 267B, 268B, 272C, 277C, 277C2, 279C, 279C2, 287C, 287C2, 289C, 289C2, 297C, 299C, 315, 315B, 315C, 317B LN, 318B, 906

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## Valve Insert - Cont'

Part No.	Description	Engine	Equipment
1070265	VALVE SEAT INSERT (EXHAUST)	3304, 3304B, 3306, 3306B, 3306C	120G, 12G, 12H, 12H ES, 12H NA, 130G, 140G, 140H, 140H ES, 140H NA, 143H, 14G, 14H NA, 160G, 160H, 160H ES, 160H NA, 163H NA, 235B, 330, 330 L, 330B L, 350, 515, 517
1070268	VALVE SEAT INSERT (INLET)	3304, 3304B, 3306, 3306B, 3306C,	120G, 12G, 12H, 12H ES, 12H NA, 130G, 140G, 140H, 140H ES, 140H NA, 143H, 14G, 14H NA, 160G, 160H, 160H ES, 160H NA, 163H NA, 1673C, 235B, 330, 330 L, 3304, 3304B, 3306, 3306B, 3306C, 330B L, 350, 515
1085912	VALVE SEAT INSERT (INLET)	3406E	R2900
1093428	VALVE SEAT INSERT (EXHAUST)	3054, 3056	307, 416B, 416C, 426C, 428B, 428C, 436C, 438C, CB-434B, CB-434C, CB-544, CB-545, CP-433C, CS-323C, CS-431C, PS-150B, PS-200B, PS-300B, TH103, TH62, TH63, TH82, TH83
1225963	VALVE SEAT INSERT (INLET)	G3512, G3516, G3516B, PMG3516	
1227352	VALVE SEAT INSERT (INLET)	931C, G3406, G3408, G3408B, G3408C, G3412, G3412C	
1233287	VALVE SEAT INSERT (EXHAUST)	3054, 3056	914G, IT14G, M312, M315
1241223H2	VALVE SEAT INSERT (INLET)		S6D114E, SA6D114E, SAA6D114E, WA320, WA380, WA420
1301501	VALVE SEAT INSERT (INLET)	3054, 3056	307, 416B, 416C, 426C, 428B, 428C, 436C, 438C, 914G, CB-434B, CB-434C, CB-544, CB-545, CP-433C, CS-323C, CS-431C, IT14G, M312, M315, PS-150B, PS-200B, PS-300B, TH62, TH63, TH82, TH83
1302607	VALVE SEAT INSERT (INLET)	3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C	5130, 5130B, 5230, 5230B, 776C, 776D, 777, 777B, 777C, 777D, 784B, 784C, 785, 785B, 785C, 785D, 789, 789B, 789C, 789D, 793B, 793C, 793D, 797
1302608	VALVE SEAT INSERT (EXHAUST)	3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C	5130, 5130B, 5230, 5230B, 776C, 776D, 777, 777B, 777C, 777D, 784B, 784C, 785, 785B, 785C, 785D, 789, 789B, 789C, 789D, 793B, 793C, 793D, 797
1314340	VALVE SEAT INSERT (EXHAUST)	3508, 3508B, 3512, 3512B, 3516, 3516B, 5130B, 5230B	776D, 777, 777D, 785C, 789C, 793C, 854G, 992G, 994D, D11R
1336997	VALVE SEAT INSERT (EXHAUST)	3176B, 3176C, 3196, C-10, C-12	345B L, 75C, 75D, 85C, 85D, 95E
1337030	VALVE SEAT INSERT (EXHAUST)	3176, 3176B	75C, 85C
1382006	VALVE SEAT INSERT (INLET)	3176B, 3176C, 3196,	140H, 143H, 14H, 160H, 163H, 16H, 345B, 345B II, 345B II MH, 345B L, 365B, 365B II, 365B L, 480, 572R II, 65E, 725, 730, 75C, 75D, 75E, 814F, 815F, 816F, 85C, 85D, 85E, 95E, 966G
1456853	VALVE SEAT INSERT (INLET)	3054, 3056	312B L, 315B L, 416C, 416D, 420D, 426C, 428C, 428D, 430D, 432D, 436C, 438C, 438D, 442D, 908, 924G, 924GZ, CB-434C, CS-323C, CS-663E, CS-683E, PS-150B
1456854	VALVE SEAT INSERT (EXHAUST)	3054, 3056	312B L, 315B L, 416C, 416D, 420D, 426C, 428C, 428D, 430D, 432D, 436C, 438C, 438D, 442D, 908, 924G, 924GZ, CB-434C, CS-323C, CS-663E, CS-683E, PS-150B
1478218	VALVE SEAT INSERT (EXHAUST)	3126, 3126B, 3126E	120H, 120K, 12K, 12M, 135H, 140K, 140M, 160K, 322C, 322C FM, 324D, 324D L, 324D LN, 325C, 325C FM, 325D, 325D L, 328D LCR, 561N, 570B, 580B, 938G II, 950G II, 950H, 953C, 962G II
1527582	VALVE SEAT INSERT (EXHAUST)	3406E, 3456	365C, 365C L, 385B, 385C, 385C FS, 385C L, 385C L MH, 5090B, 583T, 587T, 621G, 623G, 627F, 627G, 631G, 637G, 651B, 657B, 657E, 657G, 735, 740, 770, 772, 824C, 824G II, 824H, 825G II, 825H

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## Valve Insert - Cont'

Part No.	Description	Engine	Equipment
1559504	VALVE SEAT INSERT (INLET)	3126, 3126B, 3126E	120H, 135H, 322C, 322C FM, 325C, 325C FM, 561N, 570B, 580B, 938G II, 950G II, 953C, 962G II, 963C, C7, D5N, D6N, IT38G II, IT62G II, M325C MH
1639063	VALVE SEAT INSERT (INLET)	3116, 3126	120H, 120H ES, 120H NA, 135H, 135H NA, 30/30, 320B, 322B L, 322B LN, 322C, 322C FM, 325B L, 35, 45, 525B, 533, 535B, 539, 543, 55, 550, 561M, 570, 574, 580, 613C II, 928G, 938F, 938G, 950F
1753617	VALVE SEAT INSERT (INLET)	3406E, 3456	365C, 365C L, 385B, 385C, 385C FS, 385C L, 385C L MH, 5090B, 583T, 587T, 621G, 623G, 627F, 627G, 631G, 637G, 651B, 657B, 657E, 657G, 735, 740, 770, 772, 824C, 824G II, 824H, 825G II, 825H
1767688	VALVE SEAT INSERT (INLET)	C-9, C9	12H, 330C, 330C FM, 330C L, 330C MH, 627G, 637D, 637G, 973C, D6R II, MTC735, TK711, TK721, TK722, TK732, TK741, TK751, TK752
1767690	VALVE SEAT INSERT (EXHAUST)	C-9, C9	12H, 330C, 330C FM, 330C L, 330C MH, 627G, 637D, 637G, 973C, D6R II, MTC735, TK711, TK721, TK722, TK732, TK741, TK751, TK752
1799453	VALVE SEAT INSERT (EXHAUST)	3176C, 3196, C-10	140H, 143H, 14H, 160H, 163H, 16H, 345B, 345B II, 345B II MH, 345B L, 365B, 365B II, 365B L, 480, 572R II, 65E, 725, 730, 75C, 75E, 814F, 815F, 816F, 85C, 85E, 95E, 966G II, 972G II,
1799454	VALVE SEAT INSERT (INLET)	3176C, C-10, C-12	CPT372, R1600, R1600G, R1700G, SBF214, SUF557
1838809	VALVE SEAT INSERT (INLET)	3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C	776C, 776D, 777D, 784C, 785, 785B, 785D, 789C, 793D, D11N, PM3516, SPF343C, TH48-E80, TH55-E70, XQC1200, XQC1600
1916760	VALVE SEAT INSERT (EXHAUST)	G3508, G3508B, G3512, G3512B, G3516, G3516B, G3520B	PMG3516
1986529	VALVE SEAT INSERT (EXHAUST)	G3406, G3408, G3408B, G3408C, G3412	
2N8943	VALVE SEAT INSERT (INLET)	1140, 1160, 3160, 3204, 3208,	215, 613B, 613C, 926, 943, 953, D4HTSK II, PR-1000, PS-500
2120936	VALVE SEAT INSERT (EXHAUST)	G3406, G3408, G3408B, G3408C, G3412	CG137-08, CG137-12
2128474	VALVE SEAT INSERT (INLET)	3064, 3066	311C, 312C, 312C L, 314C, 318C, 319C, 320C, 320C FM, 320C L, 320D, 320D LRR, 321C, 323D L, 323D LN
2128917	VALVE SEAT INSERT (EXHAUST)		140M, 140M 2, 160M, 160M 2, 2290, 2390, 2391, 2491, 2590, 330D, 330D FM, 330D L, 330D LN, 330D MH, 336D, 336D L, 336D LN, 336D2, 336D2 L, 340D L, 340D2 L, 511, 521, 521B, 522, 522B, 532, 541, 541 2
2143286	VALVE SEAT INSERT (INLET)	G3406, G3408, G3408B, G3408C, G3412, G3412C	CG137-08, CG137-12
2168332	VALVE SEAT INSERT (INLET)	3056E	550B, 560B, 564, 574B, 924G, 924GZ, 930G, AP-655C, BB-760, CP-573E, CP-663E, CS-563E, CS-583E, CS-663E, CS-683E, IT28G, M316C, M318C, M318C MH, M322C
2168333	VALVE SEAT INSERT (EXHAUST)	3056E	550B, 560B, 564, 574B, 924G, 924GZ, 930G, AP-655C, BB-760, CP-573E, CP-663E, CS-563E, CS-583E, CS-663E, CS-683E, IT28G, M316C, M318C, M318C MH, M322C
2175213	VALVE SEAT INSERT (INLET)	3126, 3126B, 3126E	120H, 120K, 12K, 12M, 135H, 140K, 140M, 160K, 322C, 322C FM, 324D, 324D L, 324D LN, 325C, 325C FM, 325D, 325D L, 328D LCR, 561N, 938G II, 950G II, 950H, 953C, 962G II, 962H, 963C
2241270	VALVE SEAT INSERT (EXHAUST)		14M, 16M, 345C, 345C L, 345C MH, 345D, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L HVG, 349E L VG, 349F L, 621H, 621K, 623H, 623K, 623K LRC, 627H, 627K, 627K LRC, 725, 730, 730C, 966H, 972H

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## Valve Insert - Cont'

Part No.	Description	Engine	Equipment
2242410	VALVE SEAT INSERT (INLET)	C11, C13	725, 730, CX31-C13I, TH35-C13I
2243983	VALVE SEAT INSERT (INLET)	3406E, 3456	24M, 365C, 365C L, 365C L MH, 385B, 385C, 385C FS, 385C L, 385C L MH, 5090B, 583T, 587T, 621G, 623G, 627F, 627G, 631D, 631G, 637G, 651B, 657B, 657E, 657G, 735, 740, 770, 772, 773F, 773G
2265561	VALVE SEAT INSERT (EXHAUST)	3406E, 3456	24M, 365C, 365C L, 365C L MH, 385B, 385C, 385C FS, 385C L, 385C L MH, 5090B, 583T, 587T, 621G, 623G, 627F, 627G, 631D, 631G, 637G, 651B, 657B, 657E, 657G, 735, 740, 770, 772, 773F, 773G
2321285	VALVE SEAT INSERT (EXHAUST)	3126, 3126B, 3126E	120H, 120K, 120K 2, 12K, 135H, 140G, 140K, 140K 2, 140M, 160K, 322C, 324D, 324D FM, 324D FM LL, 324D L, 324D LN, 325C, 325D, 325D FM, 325D FM LL, 325D L, 325D MH, 326D L, 328D LCR
2418388	VALVE SEAT INSERT (INLET)		140M, 140M 2, 160M, 160M 2, 2290, 2390, 2391, 2491, 2590, 330D, 330D FM, 330D L, 330D LN, 330D MH, 336D, 336D L, 336D LN, 336D2, 336D2 L, 340D L, 340D2 L, 511, 521, 521B, 522, 522B, 532, 541, 541 2
2562084	VALVE SEAT INSERT (INLET)	3011C, 3013C, 3024, 3024C,	216B, 216B3, 226B, 226B3, 232B, 242B, 247B, 247B3, 257B, AP-255E, BB-621C, C1.1, C1.5, C2.2, CB-14, CB-214E, CB-22, CB-334E, CB-34, CB22B, CB24B, CB32B, CB34B, CB34B XW
2562085	VALVE SEAT INSERT (INLET)	3011C, 3013C, 3014, 3024, 3024C,	216B, 216B3, 226B, 226B3, 232B, 242B, 247B, 247B3, 257B, AP-255E, BB-621C, C1.1, C1.5, C1.6, C2.2, CB-14, CB-214E, CB-22, CB-334E, CB-34, CB22B, CB24B, CB32B, CB34B
2579166	VALVE SEAT INSERT (INLET)	G3508, G3512, G3516, G3520B	
2604855	VALVE SEAT INSERT (INLET)		14M, 16M, 345C, 345C L, 345C MH, 345D, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L HVG, 349E L VG, 349F L, 621H, 621K, 623H, 623K, 623K LRC, 627H, 627K, 627K LRC, 725, 730, 730C, 966H, 972H
2646157	VALVE SEAT INSERT (INLET)	3126, 3126B, 3126E,	120H, 120K, 120K 2, 12K, 135H, 140G, 140K, 140K 2, 140M, 160K, 322C, 324D, 324D FM, 324D FM LL, 324D L, 324D LN, 325C, 325D, 325D FM, 325D FM LL, 325D L, 325D MH, 326D L, 328D LCR
2668718	VALVE SEAT INSERT (INLET)	G3508, G3508B, G3512, G3512B, G3516, G3516B, G3520B, PMG3516	
2803979	VALVE SEAT INSERT (INLET)		24M, 3406E, 365C, 365C L, 365C L MH, 374D L, 374F L, 385C, 385C FS, 385C L, 385C L MH, 390D, 390D L, 390F L, 583T, 587T, 621B, 621G, 623G, 627F, 627G, 631D, 631E, 631G, 633E II, 637D, 637E, 637G, 651B
2899745	VALVE SEAT INSERT (EXHAUST)	3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C	776C, 776D, 777D, 784C, 785, 785B, 785D, 789C, 793D, D11N, PM3516, SPF343C, TH48-E80, TH55-E70, XQC1200, XQC1600
3054883	VALVE SEAT INSERT (EXHAUST)		311D LRR, 312D, 312D L, 313D, 314D CR, 314D LCR, 315D L, 318D L, 319D, 319D L, 319D
3054884	VALVE SEAT INSERT (INLET)		311D LRR, 312D, 312D L, 313D, 314D CR, 314D LCR, 315D L, 318D L, 319D, 319D L, 319D LN
3229663	VALVE SEAT INSERT (EXHAUST)	3054C, 3054E	312D2, 312D2 GC, 312D2 L, 313D2, 313D2 LGP, 315C, 318D2 L, 414E, 416D, 416E, 416F, 420D, 420E, 420F, 422E, 422F, 424D, 428D, 428E, 428F, 430D, 430E, 430F, 432D, 432E, 432F, 434E, 434F
3296655	VALVE SEAT INSERT (INLET)	3054C, 3054E	312D2, 312D2 GC, 312D2 L, 313D2, 313D2 LGP, 315C, 318D2 L, 414E, 416D, 416E, 416F, 420D, 420E, 420F, 422E, 422F, 424D, 428D, 428E, 428F, 430D, 430E, 430F, 432D, 432E, 432F, 434E, 434F

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

Part No.	Description	Engine	Equipment
3770399	VALVE SEAT INSERT (INLET)		120M, 12M, 2470C, 320D GC, 320D L, 323D L, 323D2 L, 420E, 430E, 450E, 535D, 545D, 553C, 559, 613G, 914G, 924H, 924HZ, 924K, 928H, 928HZ, 930K, 938H, 938K, 950 GC, 953D, 963D, AP-600D, AP-655D, AP1000E
3770400	VALVE SEAT INSERT (EXHAUST)		120M, 12M, 2470C, 320D GC, 320D L, 323D L, 323D2 L, 420E, 430E, 450E, 535D, 545D, 553C, 559, 613G, 914G, 924H, 924HZ, 924K, 928H, 928HZ, 930K, 938H, 938K, 950 GC, 953D, 963D, AP-600D, AP-655D, AP1000E
4N5893	VALVE SEAT INSERT (INLET)	3176, 3176B, 3176C, 3196, 3406, 3406B, 3406C, 3408, 3408B, 3408C, 3408E, 3412, 3412C, 3412D, 3412E,	16G, 16H NA, 245, 24H, 345B L, 3516B, 375, 375 L, 5080, 5110B, 578, 583R, 587R, 589, 621, 621B, 621E
4S8896	VALVE SEAT INSERT EX-HAUST (.005" OVERSIZE)	D342, D342C, G342C	D8H, D8K,
4S8897	VALVE SEAT INSERT EX-HAUST (.010" OVERSIZE)	D342, D342C, G342C	D8H, D8K,
4S8898	VALVE SEAT INSERT INLET (.005" OVERSIZE)	1693, 3406, 3408, 3412, D343, D346, D348, D349, G343	245, 631C, 637D, 641B, 650B, 651E, 657, 657B, 657E, 666, 768B, 769, 772, 777, 824B, 825B, 826B, 834, 980C, 983, 988, 988B, 992, 992C, D10,
4S8899	VALVE SEAT INSERT INLET (.010" OVERSIZE)	1693, 3406, 3408, 3412, D343, D346, D348, D349, G343	245, 631C, 637D, 641B, 650B, 651E, 657, 657B, 657E, 666, 768B, 769, 772, 777, 824B, 825B, 826B, 834, 980C, 983, 988, 988B, 992, 992C, D10,
4S8902	VALVE SEAT INSERT EX-HAUST (.005" OVERSIZE)	1693, 3406, 3408, 3412, D343, D346, D348, D349	245, 631C, 637D, 641B, 650B, 651E, 657, 657B, 657E, 666, 768B, 769, 772, 777, 824B, 825B, 826B, 834, 980C, 983, 988, 988B, 992, 992C, D10,
4S8903	VALVE SEAT INSERT EX-HAUST (.010" OVERSIZE)	1693, 3406, 3408, 3412, D343, D346, D348, D349	245, 631C, 637D, 641B, 650B, 651E, 657, 657B, 657E, 666, 768B, 769, 772, 777, 824B, 825B, 826B, 834, 980C, 983, 988, 988B, 992, 992C, D10,
4S8905	VALVE SEAT INSERT EX-HAUST (.010" OVERSIZE)		676, 621, 980
4S8906	VALVE SEAT INSERT EX-HAUST (.005" OVERSIZE)	D353C, D379, D379A, D379B, D398, D398A, D398B, D399, G353D, G379, G398, G399	D9G, D9H,
4S8907	VALVE SEAT INSERT EX-HAUST (.010" OVERSIZE)	D353C, D379, D379A, D379B, D398, D398A, D398B, D399, D9G, D9H, G353D, G379, G398, G399	
4S8909	VALVE SEAT INSERT INLET (.010" OVERSIZE)	D353C, D379, D379A, D379B, D398, D398A, D398B, D399, D9G, D9H, G353D, G379, G398, G399	
4S8912	VALVE SEAT INSERT INLET (.005" OVERSIZE)	D342, D342C, G342C	D8H, D8K
4W4325	VALVE SEAT INSERT (EXHAUST)	G3406, G3408, G3408B, G3412	
5I8011	VALVE SEAT INSERT (INLET)		311B, 311C, 312, 312B, 312C L, 320 L, 320B, 320B L, 320C, 320C FM
5I8012	VALVE SEAT INSERT (EXHAUST)		311B, 311C, 312, 312B, 312C, 312C L, 314C, 318C, 319C, 320 L, 320B, 320B L, 320C, 320C FM, 320C L, 320D, 320D LRR, 321C, 323D L, 323D LN
5S1757	VALVE SEAT INSERT (INLET)	D353C, D379, D379A, D379B, D398, D398A, D398B, D399, D9G, D9H, G353D, G379, G398, G399	594
5S7218	VALVE SEAT INSERT (INLET)	1673C, 3304, 3306, G3304, G3306	130G, 561C, 627, 814, 941, 950, 955K, 955L, 966C, 977K, 980B, D4D, D5, D6C, D7F, D7G,

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.



Part No.	Description	Engine	Equipment
6I1197	VALVE SEAT INSERT (INLET)	3054, 3056	312, 315, 317, 416C, AP-800C, BG-225B, CB-534B, CB-534C, CB-535B, CP-433C, CS-431C, TH62
6I1713	VALVE SEAT INSERT (GAS)	G3508, G3512, G3516, G3516B, G3520B, PMG3516	
6I4019	VALVE SEAT INSERT (INLET)	G3406, G3408, G3408B, G3412	
7C5335	VALVE SEAT INSERT INLET (.005" OVERSIZE)		
7C7604	VALVE SEAT INSERT INLET (.020" OVERSIZE)	3406B, 3406C, 3406E, 3408, 3408B, 3408C, 3408E, 3412, 3412C, 3412D, 3412E, 3516B,	16G, 16H NA, 24H, 375, 375 L, 5080, 5110B, 578, 583R, 587R, 589, 621E, 621F, 623E, 623F, 627E, 627F, 631D, 631E, 631G
7C7605	VALVE SEAT INSERT INLET (.030" OVERSIZE)	3406B, 3406C, 3406E, 3408, 3408B, 3408C, 3408E, 3412, 3412C, 3412D, 3412E, 3516B,	16G, 16H NA, 24H, 375, 375 L, 5080, 5110B, 578, 583R, 587R, 589, 621E, 621F, 623E, 623F, 627E, 627F, 631D, 631E, 631G
7N1649	VALVE SEAT INSERT (EXHAUST)	G3304, G3304B, G3306, G3306B	
7W0028	VALVE SEAT INSERT (GAS)	G3508, G3512, G3516	
7W1581	VALVE SEAT INSERT (EXHAUST)		206, 212, 214, 416, C280-6, C280-8, CS-431B, PS-110
7W8065	VALVE SEAT INSERT (INLET)	3114, 3116,	205B, 214B, 224B, 320 L, 325, 446B, 446D, 613C II, 918F, 924F, 928F, 938F, 950F, 950F II, 953B, 960F, 963B, AP-1000, AP-1000B, AP-1050, AP-1055B, BG-2455C, BG-245C, CB-434, CB-634C, CP-563
8M4014	VALVE SEAT INSERT (EXHAUST)	D353C, D379, D379A, D379B, D398, D398A, D398B, D399	594, D9G, D9H
8M9810	VALVE SEAT INSERT (EXHAUST)	D342, D342C, G342C	D8H, D8K
9M3205	VALVE SEAT INSERT (INLET)	1693, D343, D346, D348, D349, G343	631C, 641B, 650B, 651, 657, 657B, 666, 768B, 769, 772, 777, 824B, 825B, 826B, 834, 983, 988, 992, D10,
9M6495	VALVE SEAT INSERT (EXHAUST)	1673, 1673B	12E, 561B, 951B, 955H, 955K, 977H, 977K, D330A, D330B, D333A, D333B, D4D
9M8745	VALVE SEAT INSERT (INLET)	D342, D342C, G342C	D8H, D8K
9N0181	VALVE SEAT INSERT (INLET)		943
9N2837	VALVE SEAT INSERT (EXHAUST)	3204, 3208,	215, 225, 613B, 613C, 926, 931B, 943, 953, D4HTSK II, PR-1000, PS-500

## Valve Insert For Komatsu®

Part No.	Description	Engine	Equipment
6216-11-1330	VALVE SEAT INSERT (INLET)	SA12V140, SA6D140, SA6D140E, SAA12V140E, SAA12V140Z, SAA6D140E	330M, DCA, EGS1000, EGS1050, EGS1200, EGS500, EGS570, EGS630, HD785, HM350,

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.