



STEPS

CTP Steps offer reliability and stability at the moment you need it the most! Your safety is important to us; for that reason, we guarantee quality steps in order for you to finish your job safe and sound! Check out our Brand New Steps Now!



EQUIPMENT STEPS

Part No.	Description	Application
1061430	STEP AS	320B, 325B L, 330B L, 345B L, 814F, 814F II, 815F, 815F II, 824G, 824G II, 824H, 825G, 825G II, 825H, 938F, 950F, 950F II, 960F, 966F, 966F II, 970F, 980F II, IT38F
1987379	STEP AS	120G, 120H, 120H ES, 120H NA, 12G, 12H, 12H ES, 12H NA, 130G, 135H, 135H NA, 140G, 140H, 140H ES, 140H NA, 143H, 160G, 160H, 160H ES, 160H NA, 163H, 163H NA
1987380	STEP AS	120G, 120H, 120H ES, 120H NA, 120K, 120K 2, 12G, 12H, 12H ES, 12H NA, 12K, 130G, 135H, 135H NA, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 143H, 14G, 14H, 14H NA, 160G, 160H, 160H ES, 160H NA, 160K
2234472	STEP AS	621G, 623G, 627G, 637G, 651E, 657E, 657G, 769D, 770, 770G, 771D, 772, 772G, 773D, 773E, 773F, 773G, 773G LRC, 775E, 775F, 775G, 775G LRC, 776C, 776D, 777D, 777F
2341530	STEP AS	318C, 320C, 325C, 330C, 345B II, 938G II, 938H, 950G II, 950H, 950K, 962G II, 962H, 962K, 966G II, 966H, 966K, 972G II, 972H, 972K, 980G II, 980H, 980K, IT38H, IT62H
4V9809	STEP AS	120G, 120H, 120H ES, 120H NA, 120K, 120K 2, 12G, 12H, 12H ES, 12H NA, 12K, 130G, 135H, 135H NA, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 143H, 14G, 14H, 14H NA, 160G, 160H, 160H ES, 160H NA, 160K
4V9810	STEP AS	24H, 24M, 561M, 784B, 784C, 785B, 785C, 789B, 789C, 793B, 793C, 797, 797B, 824C, 825C, 826C, CP-433B, CP-563, CS-323C, CS-531C, CS-531D, CS-533C, CS-533D, CS-551, CS-563C, CS-563D, CS-573C, CS-573D
7T5140	STEP AS	14G, D10N, D11N, D11R, D6T LGP, D6T XL, D7E, D8N, D8R, D8R II, D8T, D9N, D9R, D9T
8W3430	STEP AS	615C, 621E, 623E, 627E, 631E, 637E, 651E, 657E

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.



SUPPORT STEPS

Part No.	Description	Application
1067782	SUPPORT-STEP	330B L, 345B L, 938F, 950F, 950F II, 960F, 966F, 966F II, 970F, IT38F
1148725	SUPPORT-STEP	784B, 784C, 785B, 785C
1414043	SUPPORT-STEP	14G, 14H, 14H NA, 14M, 16G, 16H, 16H NA, 16M, 24H, 24M
2512290	SUPPORT-STEP	120M, 120M 2, 12M, 12M 2, 12M 3, 12M 3 AWD, 140M, 140M 2, 140M 3, 140M 3 AWD, 160M, 160M 2, 160M 3, 160M 3 AWD
2944530	SUPPORT-STEP	785B, 785C, 785D, 789B, 789C, 789D, 793C, 793D, 793F, 793F AC, 793F CMD, 793F-XQ, 795F AC, 797F
3552490	SUPPORT-STEP	834H, 834K, 844H, 854K, 988H, 988K, 990H, 992K, 993K, 994H
8X1032	SUPPORT-STEP	120G, 120H, 120H ES, 120H NA, 120K, 120K 2, 12G, 12H, 12H ES, 12H NA, 12K, 130G, 135H, 135H NA, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 143H, 160G, 160H, 160H ES, 160H NA, 160K, 163H, 163H NA



BRACKET & PLATE

Part No.	Description	Application
1355154	BRACKET	834G, 834H, 844, 844H, 854G, 854K, 988F II, 988G, 988H, 990 II, 990H, 992G, 992K
3559578	BRACKET	834H, 834K, 844H, 844K, 988H, 988K, 990H, 990K, 994H
1141244	PLATE	785D, 789B, 789C, 789D, 793B, 793C, 793D, 793F, 793F AC, 793F CMD, 793F-XQ, 795F AC, 797F

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only.