



TRACK FRAME & ROLLER GUARDS

Keep your machine in top shape with our rollers guards. Essential to have installed on your machine, no matter what kind of terrain you'll be working in. Designed to mount on the track frame, these guides help maintain the alignment and prevent the steel tracks from falling off. Without roller guards, the likelihood of your tracks slipping or becoming misaligned increases, and both of those problems can lead to expensive downtime.

Part No.	Description	Application
1110416	GUARD AS	572R, D7H, D7R
1110419	GUARD ASSEM. (L.H.)	572R, D7H, D7R
1175553	GUARD AS-TRACK GUIDE	311, 311B, 312, 312B, 320 L, 320B, 320C, 320N, 322B, 322B L,
1195473	GUARD AS-TRACK GUIDE	325B, 325B L
1195474	GUARD AS-TRACK GUIDE	325B, 325B L
1207169	GUARD AS-TRACK GUIDE	320B, 320B FM LL, 320C, 320C FM
1271203	GUARD AS-TRACK GUIDE	330B, 330B L
1271204	GUARD AS-TRACK GUIDE	330B, 330B L
1332504	GUARD AS-TRACK GUIDE	330B, 330B L
1332554	GUARD AS-TRACK GUIDE	311B, 311C, 311D LRR, 311F LRR, 312B, 312B L, 312C, 312C L, 312D, 312D L, 312D2, 312D2 L, 312E, 312E L, 314C, 314D CR, 314D LCR, 314E CR, 314E LCR
1475331	GUARD AS	D10R, D10T, D10T2
1475332	GUARD AS	D10R, D10T, D10T2
1483095	GUARD AS-TRACK GUIDE	365B, 365B II, 365B L, 365C, 365C L, 365C L MH, 374D L, 374F L, 385C

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

Part No.	Description	Application
1531624	GUARD AS-TRACK GUIDE	345B II, 345B L, 345C, 345C L, 345D, 345D L, 349D, 349D L
1571606	GUARD AS-TRACK GUIDE	345B, 345B II, 345B II MH, 345B L, 345C, 345C L, 345C MH, 345D L, 345D L VG, 349D L, 349E, 349E L, 349E L VG, 349F L
1893861	GUARD AS-TRACK GUIDE	325C, 328D LCR, 330C, 330C L, 330C MH, 330D, 330D L, 330D LN, 330D MH, 336D, 336D L, 336D LN, 336D2, 336D2 L, 336E, 336E H, 336E HVG, 336E L, 336E LH, 336E LN, 336F L, 340D L, 340D2 L
1893862	GUARD AS-TRACK GUIDE	325C, 328D LCR, 330C, 330C L, 330C MH, 330D, 330D L, 330D LN, 330D MH, 336D, 336D L, 336D LN, 336D2, 336D2 L, 336E, 336E H, 336E HVG, 336E L, 336E LH, 336E LN, 336F L, 340D L, 340D2 L
1928303	GUARD AS-TRACK GUIDE	325C, 328D LCR, 330C, 330C L, 330D, 330D L, 330D LN, 330D MH, 336D, 336D L, 336D LN, 336D2, 336D2 L, 336E, 336E H, 336E L, 336E LH, 336E LN, 336F L, 340D L, 340D2 L
2029601	GUARD AS	325C
2068961	GUARD AS	320B, 320C
2198469	GUARD AS-TRACK GUIDE	315C, 318B, 318C, 319C, 319D, 319D L, 319D LN, 320B, 320C, 320C FM, 320C L, 320D, 320D FM, 320D L, 320D LRR, 320D RR, 320D2, 320D2 L, 320E, 320E L, 320E LN, 320E LRR, 320E RR, 321C, 321D LCR, 323D L
2357774	GUARD AS-TRACK GUIDE	325D, 325D L, 329D, 329D L, 329D LN, 329E, 329E L, 329E LN
2357775	GUARD AS-TRACK GUIDE	325D, 325D L, 329D, 329D L, 329D LN, 329E, 329E L, 329E LN
2402988	GUARD AS-TRACK GUIDE	311C, 314E CR, 315, 315B L, 315C, 315D L, 316E L, 317, 317B LN, 318B, 318C, 318D L, 318D2 L, 318E L, 319C, 319D, 319D L, 319D LN, 320B, 320C, 320C L, 320D, 320D FM, 320D GC, 320D L, 320D LN, 320D LRR
2495500	GUARD AS	973, 973C
2512473	GUARD AS-TRACK GUIDE	330C, 330D L, 330D MH, 345B II, 345C, 345C L, 345C MH, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L HVG, 349E L VG, 349F L
2512474	GUARD AS-TRACK GUIDE	330C, 330D L, 330D MH, 345B II, 345C, 345C L, 345C MH, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L HVG, 349E L VG, 349F L
1M1471	GUARD ASSEM.	D8H
1M9029	PLATE	571G, 572G, D7F, D7G, D7G2
1P0963	GUARD ASSEM.	235, 955L, D6C
1V8176	GUARD ASSEM. (front inner)	955K, 955L
2S6263	GUARD ASSEM. (R.H.)	D6C, D6D, D6F SR
2S6264	GUARD ASSEM. (L.H.)	D6C, D6D, D6F SR
3K3420	GUARD AS	941, 951B, 955H, D4D, D4E, D4E SR
3K9249	GUARD	941, D4D, D4E, D4E SR
3P3755	GUARD ASSEM. (R.H.)	D8K
3P4197	GUARD AS-IDLER	D7G, D7G2
3P6955	GUARD ASSEM. ROLLER	594H, D9G, D9H
3S3917	GUARD ASSEM. (R.H.)	571G, 572G, D7F, D7G, D7G2
3S3918	GUARD ASSEM. (L.H.)	571G, 572G, 633D, 637D, D7F, D7G, D7G2
3S8735	GUARD ASSEM. (R.H.)	583K, 983, D8H, D8K
3S8736	GUARD ASSEM. (L.H.)	583K, 983, D8H, D8K
3T7192	GUARD AS	D7H
3T7195	GUARD AS	D7H
3V3484	GUARD AS	D4D, D4E, D4E SR
3V3552	GUARD AS	D4D, D4E, D4E SR
3W8407	GUARD AS	943, 953
3W8410	GUARD AS	943, 953
4I5071	GUARD AS-TRACK GUIDE	330, 330 FM L, 330 L
4I6514	GUARD AS-TRACK GUIDE	330, 330 FM L, 330 L
4I6735	GUARD AS-TRACK GUIDE	320 L, 320N
4S5049	GUARD ASSEM. (R.H.)	D6C, D6D, D6E, D6E SR, D6F SR, D6G, D6G SR, D6G2 LGP, D6G2 XL
4S5050	GUARD ASSEM. (L.H.)	D6C, D6D, D6E, D6E SR, D6F SR, D6G, D6G SR, D6G2 LGP, D6G2 XL
5A6897	GUARD	D5, D5B, D5E
5A6898	GUARD	D5, D5B, D5E
5K6350	GUARD ASSEM. (LEFT HAND)	955K, 955L

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

Part No.	Description	Application
5K7141	GUARD ASSEM.	D4D
5M2971	GUARD ASSEM.	D7F
5M6673	GUARD (R.H. Outer - L.H. Inner)	583K, 983, 983B, D8H, D8K
5M6674	GUARD (R.H. Inner - L.H. Outer)	583K, 983, 983B, D8H, D8K
5S0162	GUARD ASSEM.	D8H, D8K
5S0163	GUARD ASSEM.	D8H, D8K
6I9034	GUARD AS	D6H, D6H II, D6H XL, D6H XR
6P5172	GUARD GROUP (R.H.)	D7G
6P5173	GUARD GROUP (L.H.)	D7G
6P7625	GUARD AS-TRACK ROLLER	D7G, D7G2
6P8903	GUARD GROUP (R.H.)	D8H, D8K
6P8904	GUARD GROUP (L.H.)	D8H, D8K
7G8513	GUARD AS	D6D, D6E, D6E SR, D6G, D6G SR, D6G2 LGP
7G8517	GUARD AS	D6D, D6E, D6E SR, D6G, D6G SR, D6G2 LGP
7K2943	GUARD ASSEM. (R.H.)	941, D4D, D4E, D4E SR
7K2944	GUARD ASSEM. (L.H.)	941, D4D, D4E, D4E SR
7K3005	GUARD-TRACK GUIDE	941, D4D, D4E, D4E SR
7K3711	GUARD ASSEM. (Front-Outer) ROLLER	951B, 955K, 955L
7K3714	GUARD ASSEM. (L.H.) ROLLER	951B, 955K, 955L
7M0457	GUARD	D6C, D6D, D6F SR
7M5337	GUARD ASSEM. (R.H.)	571G, 572G, 977K, 977L, D7F, D7G, D7G2
7M5338	GUARD ASSEM. (L.H.)	571G, 572G, 977K, 977L, D7F, D7G, D7G2
7Y2581	GUARD AS-TRACK GUIDE	320B, 320C, 322B L, 322C, 323D LN, 323D SA, 323E L, 325, 325 LN, 325B, 325B L, 325C, 325D, 325D L, 325D MH, 329D, 329D L, 329D LN, 329E, 329E L, 329E LN, 330C, 330D L, 336D L
8M6217	GUARD-IDLER	955K, 955L, D6C, D6D, D6E, D6E SR, D6G, D6G SR, D6G2 LGP, D6G2 XL
8M6218	GUARD-IDLER	955K, 955L, D6C, D6D, D6E, D6E SR, D6G SR, D6G2 LGP, D6G2 XL
8M7207	GUARD AS-FRAME-RH	D6C, D6D, D6E, D6E SR, D6F SR, D6G, D6G SR, D6G2 LGP, D6G2 XL
8M7208	GUARD ASSEM. (L.H.)	D6C, D6D, D6E, D6E SR, D6F SR, D6G, D6G SR, D6G2 LGP, D6G2 XL
8P4111	GUARD AS	D5, D5B, D5E
8P6274	GUARD ASSEM. (L.H.)	D7F, D7G, D7G2
8P6275	GUARD ASSEM. (R.H.)	D7F, D7G, D7G2
8Y6671	GUARD AS	963, 963B, 963C, 963D
8Y6672	GUARD AS	963, 963B, 963C, 963D
9S1043	GUARD ASSEM.	977K, 977L, D7F, D7G
9S1044	GUARD ASSEM. (front inner & rear) ROLLER	977K, 977L, D7F, D7G
9S8257	GUARD AS-GUIDING ROLLER	330D L, 3516, D5, D5B, D6C, D6D
9S8258	GUARD ASSEM.	D5, D5B, D6C, D6D
9S8358	GUARD ASSEM. (Front Outer) ROLLER	D5, D5B
9S8359	GUARD ASSEM. ROLLER	D5, D5B
9U8468	GUARD AS	D6H, D6H XL, D6H XR, D6R, D6R II, D6T, D6T LGP
9V5749	GUARD GP-RECOIL SPRING	D4E

TRACK FRAME & ROLLER GUARDS FOR KOMATSU®

Part No.	Description	Application
14X-30-11312	GUARD,R.H. (WELDED)	D60P, D65E, D65EX, D65P, D65PX, D70LE, D85E, D85ESS
195-30-67250	GUARD	D375A

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.