



HYDRAULIC CYLINDER HEADS

Hydraulic cylinder heads are designed to maintain hydraulic pressure by closing off the opposite end of the hydraulic cylinder. The head contains seals and bearings, that seal the barrel head opening and align the piston rod. If you need a replacement cylinder head that can withstand extreme pressure, shop our selection of Hydraulic Cylinder Heads today.

Part No.	Application
0875434	1390, 2590, 320 L, 320B, 320C, 320D, 320D FM, 320D2, 320D2 L, 322 FM L, 322 LN, 322B L, 322B LN, 322C, 322C FM, 323D L, 323D LN, 323D SA, 324D, 324D FM, 324D FM LL, 324D L, 324D LN, 325B L, 325C, 325C
0875551	325B L, 325C, 330, 330 FM L, 330 L, 330B, 330B L, 330C, 330C L, 330C MH, 330D, 330D L, 330D LN, 330D MH, 336D, 336D L, 340D L, 345B II, 345B II MH, 345B L, 345C, 345D, 345D L, 345D L VG, 349D, 349D L
1066267	844, 844H, 844K, D9N
1073950	24H, 416B, 416C, 428B, 428C, 438C, 773D, 773E, 777D
1118192	980G, 980G II, 980H
1206677	416B, 416C, 416D, 424D, 428B, 428C, 438C
1206679	24H, 24M, 928F, 928G, 928HZ, 938F, 953C, D5M, D5N, IT18F, IT24F, IT28F, IT28G
1213395	14H, 14H NA, 14M, 16H, 16H NA, 16M, 426B, 426C, 436C, 938F, 938G, 938G II
1242726	950B/950E, 950F, 950F II, 960F, 966D, 966F, 966F II, 970F, 992C, 992D, R1300, R1300G, R1300G II, R1600
1262043	318B, 318C, 319C, 319D, 319D L, 319D LN, 320 L, 320B, 320C, 320D, 320D FM, 320D FM RR, 320D2, 320D2 L, 320E, 320E L, 320E LN, 320E LRR, 320E RR, 322B L, 322C, 323D L, 323D LN, 323D SA, 323E L, 324D L
1334046	966G, 966G II, 972G, 972G II
1357393	12H, 12H NA, 140H, 140H NA, 527, 930K, D5R LGP, D6M, D6N, D6N LGP
1482593	120H, 120H ES, 120H NA, 120K, 120K 2, 120M, 120M 2, 12G, 12H, 12H ES, 12H NA, 12K, 12M, 12M 2, 12M 3, 12M 3 AWD, 130G, 135H, 135H NA, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 140M, 140M 2, 140M 3

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

ENGINE OIL FILLER CAPS - CON'T.

Part No.	Application
1515349	14H, 14H NA, 16G, 16H, 16H NA, 416C, 416D, 420D, 422E, 424D, 426C, 428B, 428C, 428D, 428E, 430D, 432D, 432E, 434E, 436C, 438C, 438D, 442D, 442E, 444E, 910E, IT12B
1521863	416B, 416C, 426C, 436C, 446B, 583R, 583T, PL83
1548050	416C, 420D, 428C, 428D, 432D, 438C, 438D, 442D
1636474	D8R, D8R II, D8T
1646403	D8L, D9N, D9R, D9T
1729981	14H, 14H NA, 14M, 16G, 16H, 16H NA, 16M, 446B, 446D, 928H, 988G, 988H, D6H XL, D6R, D6R II, D6R III, D6R STD, D6T, D6T LGP, D6T LGPPAT, D6T XL, D7H, D7R, D7R II, D7R XR, IT28G
1733366	312D2, 365B, 365B II, 365C, 365C L, 375, 375 L, 385B, 385C, 385C FS, 385C L, 385C L MH, 390D, 390D L, 5080, 5090B, 5110B
1747432	416B, 416C, 428B, 428C, 438C, 611
1772611	318B, 318C, 319D L, 319D LN, 320C, 320C FM, 320C L, 320D, 320D FM, 320D GC, 320D L, 320D LN, 320D LRR, 320D RR, 320D2, 320D2 GC, 320D2 L, 320E, 320E L, 320E LN, 320E LRR, 320E RR, 321B, 321C, 321D LCR
1849843	120G, 120H, 120H ES, 120H NA, 120K, 120K 2, 120M, 120M 2, 12G, 12H, 12H ES, 12H NA, 12K, 12M, 12M 2, 12M 3, 12M 3 AWD, 130G, 135H, 135H NA, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 140M, 140M 2
1895629	416D, 420D, 430D
1915602	324D, 325C, 325D L, 328D LCR, 330C, 330C FM, 330C L, 330D, 330D FM, 330D L, 330D LN, 336D, 336D L, 340D L, 345C, 385C L
1916112	414E, 416D, 416E, 422E, 424D
1916149	420D, 420E, 428D, 428E, 430D, 430E, 432D, 432E, 438D, 442D, 442E
1916191	416D, 420D, 430D, 430E, 430F, 432D, 438D, 442D, 442E, 444E, 446D
1916558	416D, 420D, 428D, 432D, 438D, 442D
1U1805	D7G
2014826	416D, 420D, 420E, 430D, 430E, 525B, 525C, 525D, 535B, 535C, 535D, 545, 545C, 545D, 555D
2132483	416E, 422E, 428E, 432E, 434E
2142249	416E, 416F, 422E, 428E
2332594	416D, 416E, 420D, 420E, 430D, 430E
2332595	416D, 416E, 420D, 420E, 422E, 424D, 428D, 428E, 430D, 430E, 432D, 432E, 434E, 442D, 442E, 444E, 446D, 450E, 527
2359832	416C, 416D, 420D, 424D, 428D, 432D, 438D, 442D, 928HZ, 930G
2B0176	5130, 5130B, 5230, D7H, D7R, D7R II, D8R, D8R II, D8T
3588479	345B II, 345C, 345C L, 345D, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L VG, 365B, 365B II, 365C, 365C L, 365C L MH, 374F L, 385C L MH
3588521	322B L, 322C FM, 324D FM, 324D FM LL, 330B L, 330C FM, 330D FM, 345B, 345B II MH, 345C, 345C L, 345D, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L VG, 349F L, 350, 568 FM LL, M330D, W345B II
4242921	365B, 365B II, 365C, 365C L, 385B, 385C, 385C L
4T6889	426, 428, 436
4T7014	416, 416B, 416C, 426, 426B, 428, 428B, 428C, 438C
4T7586	988B
6E0122	303, 303.5C, 303.5D, 303.5E, 303C CR, 303E CR, 304C CR, 304D CR, 304E, 305.5D, 305.5E, 305C CR, 305D CR, 305E, 414E, 416B, 416C, 416D, 416E, 420D, 422E, 424D, 426B, 426C, 428B, 428C, 428D, 428E, 430D

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

ENGINE OIL FILLER CAPS - CON'T.

Part No.	Application
6E0123	12H, 12M, 12M 2, 12M 3, 12M 3 AWD, 140H, 140H ES, 140H NA, 140M, 140M 2, 140M 3, 140M 3 AWD, 143H, 160H, 160H ES, 160H NA, 160K, 160M, 160M 2, 160M 3, 160M 3 AWD, 163H, 163H NA, 416, 416B, 416C, 416D
6E0775	120K, 120M, 12G, 12H, 12H ES, 12H NA, 12K, 12M, 130G, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 140M, 143H, 14H, 14H NA, 14M, 160H, 160H ES, 160H NA, 160K, 160M, 163H, 163H NA, 16G, 16H, 16H NA, 16M
6E1405	416B, 428B, 918F, 924F
6E1816	416C, 420D, 426B, 426C, 428C, 430D, 436, 436B, 436C, 438B, 438C, 446B
6E3570	611, 615C, 980F, 980F II, D5H, D5H XL, D5R LGP, D6M, D6N, D6N LGP
6E4940	120G, 120H, 120H ES, 120H NA, 120K, 120K 2, 120M, 120M 2, 12G, 12H, 12H ES, 12H NA, 12K, 12M, 12M 2, 12M 3, 12M 3 AWD, 130G, 135H, 135H NA, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 140M, 140M 2
6E4974	120G, 120H, 120H ES, 120H NA, 120K, 120K 2, 120M, 120M 2, 12G, 12H, 12H ES, 12H NA, 12K, 12M, 12M 2, 12M 3, 12M 3 AWD, 130G, 135H, 135H NA, 140G, 140H, 140H ES, 140H NA, 140K, 140K 2, 140M, 140M 2
6E4977	16G, 16H, 16H NA, 16M, 345B II, 345B L, 345C L, 525B, 525C, 525D, 535B, 535C, 535D, 545, 545C, 545D, 555D, 910E, 910G, 914G, 918F, 924F, 980G, 980G II, 980H, D6R III, D6T, D6T LGP, D6T LGPPAT, D6T XL
6E5527	D5H XL, D6G2 LGP, D6G2 XL, D6H, D6H XL, D6H XR, D6R, D6R II, D7G2, D7H, D7R, D7R II, D7R XR, D8N, D9N
6E5651	416B, 416C, 416D, 420D, 424D, 426B, 426C, 428B, 428C, 428D, 430D, 432D, 436C, 438B, 438C, 438D, 442D, 446B, 446D
6J7513	623, 950
6J9734	769, 950
7J3043	920
7J3351	120G, 12G, 130G, 140G, 14G, 16G, 227, 627E, 637E, 657E, 910, 931B, 950
7Y4660	320 L, 320B, 320C, 320N, 322B, 322B L, 322B LN, 322C, 323D L, 324D, 324D L, 324D LN, 324E, 324E L, 324E LN, 325, 325 L, 325 LN, 325B, 325B L, 325C, 325C FM, 325C L, 325D, 325D FM, 325D L, 328D LCR
8J0119	120G, 12G, 130G, 14G, 910
8J6019	14G, D4H, D4H XL, D5H
9T0416	966C, 966R, D7G, D7G2
9T3502	966D, 966F, 966F II, 970F
9T3508	980C, 980F, 980F II, D8L, D8N, R1600, R1600G, R1600H
9T3707	930R
9T3708	930R
9T4761	D5B, D5E, D6D, D6E, D6E SR, D6G, D6G SR, D6G2 LGP, D6G2 XL, D7H, D7R
9T4762	D6H
9T4934	D6R, D6R II, D7R, D7R II, D8N
9T5822	930R
9T6090	966C
9T6347	966C
9T6863	16G, 621E, 621F, 621G, 621H, 623E, 623F, 623G, 623H, 623K, 623K LRC, 627E, 627F, 627G, 627H, 784B, 784C, 785, 785B, 785C, 785D, 973, 973C, D4E, D4E SR, D5H, D5H XL, D6H, D6H XL, D6H XR, D6M, D6N, D6R

* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.