



# ROCKER ARMS & BRIDGES

Valve geometry is super critical for the correct operation of the valves on a cylinder head. Rocker arms and bridges are subject to extreme wear, re-using these components is a sure-fire way to end up with a variety of valve sealing and oil consumption problems. When replacing cylinder heads, it is important to use new rocker arms and valve bridges to provide the correct valve geometry. Our valvetrain components have been selected for their quality and performance, as well as ease of installation and fitment.

## ROCKER ARMS

Part No.	Description	Engine	Application
1051776	ARM AS-UNIT INJECTOR	3114, 3116, 3126	120H, 120H ES, 120H NA, 135H, 135H NA, 214B, 320B, 322B L, 322B LN, 322C, 322C FM, 325, 325B, 325B L, 35, 446B, 446D, 45, 525B, 533, 535B, 539, 543, 55, 550, 561M, 570, 574, 580, 613
610924	ROCKER ARM AS IN/EX	3114, 3116, 3126	120H, 120H ES, 120H NA, 135H, 135H NA, 214B, 224B, 320B, 322B L, 322B LN, 322C, 322C FM, 325, 325B, 325B L, 35, 446B, 446D, 45, 525B, 533, 535B, 539, 543, 55, 550, 561M, 570, 574
2302621	ROCKER ARM AS IN/EX	3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C	5130B, 5230B, 776D, 777, 777B, 777C, 777D, 784C, 785, 785B, 785C, 785D, 789, 789B, 789C, 789D, 793C, 793D, 797, 797B, 854G, 992G, 994D, 994F
2816159	ROCKER ARM AS INJECTOR	3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C	5130B, 5230B, 776D, 777, 777B, 777C, 777D, 784C, 785, 785B, 785C, 785D, 789, 789B, 789C, 789D, 793C, 793D, 797, 797B, 854G, 992G, 994D, 994F
4373863	ROCKER ARM AS	3406E, 3456, C15, C18	24M, 365C, 365C L, 365C L MH, 374D L, 374F L, 385C, 385C FS, 385C L, 385C L MH, 390D, 390D L, 583T, 587T, 621G, 623G, 627F, 627G, 631D, 631E, 631G, 633E II, 637D, 637E, 637G, 651B, 657E
4373861	ROCKER ARM AS INJECTOR	3406E, 3456, C15, C18	735, 740, D400E II, PM-200, PM-201, PM620, PM622, PM820, PM822, PM825, 825C, 825K, 826C, 826G, INDUSTRIAL, GENERATOR, TRUCK
1159398	ARM-VALVE ROCKER EX	3176C, 3196, C-10, C10, C-12	140H, 143H, 14H, 160H, 163H, 16H, 3176C, 3196, 345B, 345B II, 345B II MH, 345B L, 365B, 365B II, 365B L, 480, 572R II, 65E, 725, 730, 75D, 75E, 814F, 815F, 816F, 85D, 85E, 95E, 966G II, 972G II, C-10
1159399	ARM-VALVE ROCKER IN	3176C, 3196, C-10, C10, C-12	140H, 143H, 14H, 160H, 163H, 16H, 3176C, 3196, 345B, 345B II, 345B II MH, 345B L, 365B, 365B II, 365B L, 480, 572R II, 65E, 725, 730, 75D, 75E, 814F, 815F, 816F, 85D, 85E, 95E, 966G II, 972G II, C-10
1159400	ARM AS INJECTOR	3176C, 3196, C-10, C10, C-12	140H, 143H, 14H, 160H, 163H, 16H, 3176C, 3196, 345B, 345B II, 345B II MH, 345B L, 365B, 365B II, 365B L, 480, 572R II, 65E, 725, 730, 75D, 75E, 814F, 815F, 816F, 85D, 85E, 95E, 966G II, 972G II, C-10

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## ROCKER ARMS - CON'T.

Part No.	Description	Engine	Application
1468147	ARM AS-LIFTER IN/EX	3114, 3116, 3126	120H, 120H ES, 120H NA, 135H NA, 30/30, 320B, 322B L, 322B LN, 322C, 322C FM, 325B L, 35, 446B, 446D, 45, 525B, 533, 535B, 539, 543, 55, 550, 561M, 570, 574, 580, 613C II, 924F, 928G
2781365	ROCKER ARM AS	3406E, 3456	24M, 365C, 365C L, 365C L MH, 374D L, 385B, 385C, 385C FS, 385C L, 385C L MH, 390D, 390D L, 5090B, 583T, 587T, 621B, 621G, 623G, 627F, 627G, 631D, 631E, 631G, 633E II, 637D, 637E, 637G
2W8271	ROCKER ARM AS	3204, 3208	613B, 613C, 953, CS-551, D4HTSK II, FB221, IT28, IT28B, PR-1000, PS-500
3284238	ROCKER ARM GP	3406E, 3456	24M, 365C, 365C L, 365C L MH, 374D L, 385B, 385C, 385C FS, 385C L, 385C L MH, 390D, 390D L, 5090B, 583T, 587T, 621B, 621G, 623G, 627F, 627G, 631D, 631E, 631G, 633E II, 637D, 637E, 637G
3284240	ROCKER ARM AS	3456, C-15, C-16, C-18, C16	385B, 5090B, 583T, 621B, 621G, 735, 824C, 824G, 980G, 980G II, 980H, D400E II, D8R II, PM-201, R2900G
4N5614	ROCKER ARM AS	3406, 3406B, 3406C, 3408, 3408B, 3408C, 3408E, 3412, 3412C, 3412D, 3412E	16G, 16H NA, 245, 245B, 24H, 375, 375 L, 5080, 5110B, 578, 583R, 587R, 589, 621, 621E, 621F, 623E, 623F, 627B, 627E, 627F, 631
6I1647	ROCKER ARM GP	3304, 3306, 3306B, G3304, G3304B, G3306, G3306B,	GENERATOR, INDUSTRIAL, TRUCK, MARINE
6I1650	ROCKER ARM GP	3304, 3306, 3306B, G3304, G3304B, G3306, G3306B	GENERATOR, INDUSTRIAL, TRUCK, MARINE
7E6794	ARM AS-INJECTOR	3114, 3116, 3126, 3126B, 3126E	120H, 120H ES, 120H NA, 120K, 120K 2, 12K, 12M, 135H, 135H NA, 140G, 140K, 140K 2, 140M, 160K, 214B, 224B, 320B, 322B, 322B L, 322B LN, 322C, 322C FM, 324D, 324D FM
8N3325	ROCKER ARM GP (EX)	3304, 3304B, 3306, 3306B, 3306C	120G, 12G, 12H, 12H ES, 12H NA, 130G, 140B, 140G, 140H, 140H ES, 140H NA, 143H, 14G, 14H NA, 160G, 160H, 160H ES, 160H NA, 163H NA, 1673C, 235, 235B, 330, 330B L
8N3327	ROCKER ARM GP (IN)	3304, 3304B, 3306, 3306B, 3306C	120G, 12G, 12H, 12H ES, 12H NA, 130G, 140B, 140G, 140H, 140H ES, 140H NA, 143H, 14G, 14H NA, 160G, 160H, 160H ES, 160H NA, 163H NA, 1673C, 235, 235B, 330, 330B L
9Y1741	ROCKER ARM AS	3508, 3508B, 3508C, 3512, 3516, 3516B, G3508, G3508B, G3512, G3512B, G3516, G3516B, G3520B, PM3512, PM3516, PMG3516	5130, 5230, 776C, 784B, 785, 785B, 789B, 793B, 994, D11N, D11R
2027475	LIFTER AS-UNIT INJECTOR	3176C, 3196	140H, 143H, 14H, 14M, 160H, 163H, 16H, 16M, 345B, 345B II, 345B II MH, 345B L, 345C, 345C L, 345C MH, 345D, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L HVG, 349E L VG, 349F L
2511005	LIFTER AS-VALVE	3176C, 3196	140H, 143H, 14H, 14M, 160H, 163H, 16H, 16M, 345B, 345B II, 345B II MH, 345B L, 345C, 345C L, 345C MH, 345D, 345D L, 345D L VG, 349D, 349D L, 349E, 349E L, 349E L HVG, 349E L VG, 349F L
2255625	LEVER AS	3054C, 3054E	312D2, 312D2 GC, 312D2 L, 313D2, 313D2 LGP, 315C, 318D2 L, 320D2, 320D2 GC, 320D2 L, 414E, 416D, 416E, 416F, 420D, 420E, 420F, 422E, 422F, 424D, 428D, 428E, 428F, 430D, 430E, 430F, 432D
2255640	LEVER AS	3054C, 3054E	312D2, 312D2 GC, 312D2 L, 313D2, 313D2 LGP, 315C, 318D2 L, 320D2, 320D2 GC, 320D2 L, 414E, 416D, 416E, 416F, 420D, 420E, 420F, 422E, 422F, 424D, 428D, 428E, 428F, 430D, 430E, 430F, 432D

## ROCKER ARMS FOR KOMATSU®

Part No.	Description	Engine	Application
6732-41-5200	ARM ASSEMBLY KOMATSU	S4D102E, S6D102E, SAA6D102E	50A/FA, 4D102E, 510C, 520C/CH, 6D102, 6D102E, 708, 712, 830, D32E, D38E, D39E, DCA, EGS120, GD530A/AW, PC200, PC200LL, PC220, PC220LL, PC250, PC270, PW160, PW200, PW220
6732-41-5400	ARM ASSEMBLY KOMATSU	S4D102E, S6D102E, SAA6D102E	50A/FA, 4D102E, 510C, 520C/CH, 6D102, 6D102E, 708, 712, 830, D32E, D38E, D39E, DCA, EGS120, GD530A/AW, PC200, PC200LL, PC220, PC220LL, PC250, PC270, PW160, PW200, PW220

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.

## VALVE BRIDGES

Part No.	Description	Engine	Application
2657538	BRIDGE	3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C	5130B, 5230, 5230B, 776C, 776D, 777, 777B, 777C, 777D, 784C, 785, 785B, 785C, 785D, 789, 789B, 789C, 789D, 793C, 793D, 797, 797B, 854G, 992G
1294181	BRIDGE AS	3508, 3508B, 3508C, 3512, 3512B, 3516, 3516B	5130, 5130B, 5230, 5230B, 776C, 776D, 777D, 784B, 784C, 785, 785B, 785C, 789B, 789C, 793B, 793C, 797, 797B, 854G, 992G, 994, 994D, D11N, D11R
1011816	BRIDGE AS-VALVE	3406, 3406B, 3406C, 3412, 3412C	16G, 16H NA, 375, 375 L, 5080, 578, 583R, 587R, 621E, 621F, 623E, 623F, 627B, 627E, 627F, 651E, 657E, 773B, 775B, 814B, 824G, 825G, 826C, 826G, 980C, 980F, 980G, 990
1011817	BRIDGE AS-VALVE	3406, 3406B, 3406C, 3412, 3412C, G3406, G3408, G3408B, G3408C, G3412, G3412C	16G, 627B, 627E, 651E, 657E, 773B, 775B, 826C, 980C, 990, 992C, 992D, CG137-08, CG137-12, D10N, PR-1000, PR-750B, SS-250
1764168	BRIDGE AS-VALVE	3176B, 3176C, 3196	140H, 143H, 14H, 160H, 163H, 16H, 345B, 345B II, 345B II MH, 345B L, 365B, 365B II, 365B L, 480, 572R II, 65E, 725, 730, 75C, 75D, 75E, 814F, 815F, 816F, 85C, 85D, 85E, 95E, 966G
1764172	BRIDGE AS-VALVE	3176, 3176B, 3176C, 3196, C-10, C-12	TRUCK
1011818	BRIDGE AS-EXHAUST	3406B, 3406C	16G, 16H NA, 375, 375 L, 5080, 578, 583R, 587R, 621E, 621F, 623E, 623F, 627E, 627F, 814B, 824G, 825G, 826C, 826G, 980C, 980F, 980G, D8N, D8R, D8R II, G3406, HT400, PM-465, RM-250C
2657537	BRIDGE	3508, 3508B, 3508C, 3512, 3512B, 3512C, 3516, 3516B, 3516C	5130B, 5230, 5230B, 776C, 776D, 777, 777B, 777C, 777D, 784C, 785, 785B, 785C, 785D, 789, 789B, 789C, 789D, 793C, 793D, 797, 797B, 854G, 992G
2303152	BRIDGE	3508, 3508B, 3512, 3512B, 3516B, 3516C, PM3508, PM3512, PM3516, PP3516	5130B, 5230B, 776D, 777, 777D, 784C, 785C, 789C, 793C, 797, 797B, 854G, 992G, 994D, D11N, D11R, PP3516, SPF343, SPS343, SPT343, TH55-E70
1006889	BRIDGE-VALVE	3406B, 3406C, 3408, 3408B, 3408C, 3408E, 3412, 3412C, 3412D, 3412E	16G, 16H NA, 24H, 375, 375 L, 5080, 5110B, 578, 583R, 587R, 589, 621F, 623E, 623F, 627F, 631D, 631E, 631G, 633E II, 637E, 637G, 651E
3487743	BRIDGE-VALVE	3406E, 3456	24M, 365C, 365C L, 365C L MH, 374D L, 374F L, 385B, 385C, 385C FS, 385C L, 385C L MH, 390D, 390D L, 5090B, 583T, 587T, 621B, 621G, 623G, 627F, 627G, 631D, 631E, 631G, 633E II, 637D, 637E

\* Other part no. not included in the list are available. Please contact your sales representative if you have any questions. Part Numbers are used for reference purposes only. Komatsu® is the registered trademark of Komatsu Ltd.